

Use Ctrl-F to search by Manufacturer or Model Number

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
3M	S10	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO		
3M	S15	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO	G-TourCarryOnPL	
3M	S20	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO		
3M	S40	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
3M	S50	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
3M	S55	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
3M	X40	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
3M	X45	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
3M	X50	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
3M	X55	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
3M	X65	Projector	G-TourCarryOnFO				
3M	X75	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
ACCESS	VIRUS CLASSIC	Synthesizer	GK-LT25W				
ACCESS	VIRUS TI 61	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
ACCESS	VIRUS TI DESKTOP	Synthesizer	GK-LT25W				
ACER	AL1706AB	LCD/Plasma	G-MIX-L 1618	GAV-1813R			
ACER	AL1916AB	LCD/Plasma	G-MIX-L 1618	G-MIX-L 1622			
ACER	AL1916CB	LCD/Plasma	G-MIX-L 1618	G-MIX-L 1622			
ACER	AL1916WAB	LCD/Plasma	GAV-1813R				
ACER	AL1916WABD	LCD/Plasma	GAV-1813R				
ACER	AL1917CBMD	LCD/Plasma	G-MIX-L 1618	G-MIX-L 1622	G-MIX-L 1822		
ACER	AL2016WBSD	LCD/Plasma	G-MIX-L 1622	G-TourLCDP2023			
ACER	AL2016WSD	LCD/Plasma	G-MIX-L 1622	G-MIX-L 1822	G-TourLCDP2023		
ADAM	SUB10	Studio Monitor	GPA-600	GMC-2222	GMC-3333		
ADAM	SUB8	Studio Monitor	GMC-2222				
ADAM AUDIO	SUB10 MKII	Speaker - Sub	GPA-600				
AG NEOVO	X17AV	LCD/Plasma	G-MIX-L 1822				
AG NEOVO	X19AV	LCD/Plasma	G-MIX-L 1822				
AKAI	DPS24	Recording Workstation	GMC-3333				
AKAI	DPS24-MKII	Mixer	GMC-3333				
AKAI	MPC1000	Sampler	G-TOUR 12X17				
AKAI	MPC2000XL-MCD	Sampler	G-MIX-L 1618	G-MIX 17 x 18	G-MIX 19X21	G-TOUR 19X21	GMC-2222
AKAI	MPC2500	Sampler	G-MIX-L 1618	G-MIX 17 x 18	G-MIX 19X21	G-TOUR 19X21	GMC-2222
AKAI	MPC4000 PLUS	Sampler	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222	GMC-3333
AKAI	MPD16	Digital Interface	G-MIX-B 1212				
AKAI	MPD24	Drum Machine	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	
AKAI	PDP4290	LCD/Plasma	G-TourLCDP3743				
AKAI	PDP4294	LCD/Plasma	G-TourLCDP3743				
AKAI	PDP4298ED	LCD/Plasma	G-TourLCDP3743				
AKAI	PDP4298ED1	LCD/Plasma	G-TourLCDP3743				
AKG	AS16X12	Mixer	G-MIX-L 1224	G-MIX 12 x24			
AKG	AS8	Mixer	G-MIX-L 1224	G-MIX 12 x24			
AKG	AS8TC	Mixer	G-MIX-L 1224	G-MIX 12 x24			
AKIRA -NEOART	EMP 500	LCD/Plasma	G-TourLCDP50				
AKIRA -NEOART	HPT500AW	LCD/Plasma	G-TourLCDP50				
AKIRA -NEOART	SV-4201	LCD/Plasma	G-TourLCDP3743				
AKIRA -NEOART	SV-4201H	LCD/Plasma	G-TourLCDP3743				
ALESIS	A6	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
ALESIS	CD TWIN LE	Media Player	G-MIX-B 1212	G-TOUR 12X17			
ALESIS	FUSION 6HD	Keyboard	GKB-49	GK-49	GKC-1540		
ALESIS	FUSION 8HD	Keyboard	GKB-76	GK-76	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim
ALESIS	GIGAMIX 4 CD	Powered Mixer	GMC-2222	GMC-3333			
ALESIS	GIGAMIX 4 FX	Powered Mixer	GMC-3333	GMC-4221			
ALESIS	GIGAMIX 6 FX	Powered Mixer	GMC-3333	GMC-4221			
ALESIS	GIGAMIX 8 FX	Powered Mixer	GMC-3333	GMC-4221			
ALESIS	ION	Keyboard	GKB-49	GK-49			
ALESIS	MICRON	Keyboard	GK-2110	GK-LT25W			
ALESIS	MULTIMIX 12 FIREWIRE	Mixer	G-MIX-B 1515	G-MIX 17 x 18	GMC-2222		
ALESIS	MULTIMIX 12 FX	Mixer	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	
ALESIS	MULTIMIX 12 USB	Mixer	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	
ALESIS	MULTIMIX 12FXD	Mixer	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	
ALESIS	MULTIMIX 16 FIREWIRE	Mixer	G-MIX-L 1618	G-MIX 17 x 18	G-MIX 19X21	G-TOUR 19X21	GMC-2222
ALESIS	MULTIMIX 16 USB	Mixer	G-MIX-L 1618	G-MIX 17 x 18	G-MIX 19X21	G-TOUR 19X21	GMC-2222
ALESIS	MULTIMIX 16FXD	Mixer	GMC-2222				
ALESIS	MULTIMIX 8 FW	Mixer	G-MIX-B 1212				
ALESIS	MULTIMIX 8 FX	Mixer	G-MIX-B 1212				
ALESIS	MULTIMIX 8 USB	Mixer	G-TOUR 12X17				
ALESIS	MULTIMIX12FIREWIRE	Digital Interface	G-MIX-B 1515	G-MIX 17 x 18	GMC-2222		
ALESIS	MULTIMIX16FIREWIRE	Digital Interface	G-MIX-L 1618	G-MIX 17 x 18	G-MIX 19X21	G-TOUR 19X21	GMC-2222
ALESIS	MULTIMIX8FIREWIRE	Digital Interface	G-MIX-B 1212				
ALESIS	PHOTONX25	Keyboard	GK-2110	GK-LT25W			
ALESIS	QS6.2	Keyboard	GKB-49	GK-49	GK-4212		
ALESIS	QS8.2	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	
ALESIS	STUDIO 24	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
ALLEN & HEATH	GL2200-416	Mixer	GMC-3333				
ALLEN & HEATH	GL2400 16	Mixer	GMC-3333				
ALLEN & HEATH	GL2400 24	Mixer	G-MIX 24 x 36	G-TOUR 24 x 36	GMC-3333		
ALLEN & HEATH	GL3000 816	Mixer	GMC-3333				
ALLEN & HEATH	GL3000 8M	Mixer	GMC-3333	GMC-4221			
ALLEN & HEATH	PA 12	Mixer	G-MIX-B 2020	G-MIX-L 1822	G-MIX 19X21	G-TOUR 19X21	GMC-2222
ALLEN & HEATH	PA 12-CP	Mixer	G-MIX-B 2020	G-MIX-L 1822	G-MIX 19X21	G-TOUR 19X21	GMC-2222
ALLEN & HEATH	PA-20	Mixer	G-MIX 24 x 36	G-TOUR 24 x 36	GMC-3333	GMC-4221	
ALLEN & HEATH	WZ3:12:2	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222		
ALLEN & HEATH	WZ3:12M	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222		
ALLEN & HEATH	WZ3:14:4:2	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222		

Gator Cases Master Cross Reference

Updated 9/19/07

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
ALLEN & HEATH	WZ3:16:2	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222		
ALLEN & HEATH	WZ3:20S	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222		
ALLEN & HEATH	XONE 464	Mixer	G-MIX-B 2020	G-MIX-L 1822	G-MIX 19X21	G-TOUR 19X21	GMC-2222
ALTO AUDIO	AMX 100	Mixer	G-MIX-B 1212				
ALTO AUDIO	AMX 100 FX	Mixer	G-MIX-B 1212				
ALTO AUDIO	L-12	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-MIX 19X21	G-TOUR 19X21
ALTO AUDIO	L-16	Mixer	G-MIX-B 2020	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222	
ALTO AUDIO	L-20	Mixer	G-MIX-B 2020	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222	
ALTO AUDIO	L-8	Mixer	G-MIX-B 1212				
ALTO AUDIO	PM-12 DRAGONFLY	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
ALTO AUDIO	S-12	Mixer	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	
ALTO AUDIO	S-16	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
ALTO AUDIO	S-8	Mixer	G-MIX-B 1212				
AMERICAN AUDIO	CDI 300	Pro DJ - CD Player	G-Tour-CD-13x17	G-Tour-CDMX13x17			
AMERICAN AUDIO	CDI 300 MP3	Pro DJ - CD Player	G-Tour-CD-13x17	G-Tour-CDMX13x17			
AMERICAN AUDIO	CDI 500	Pro DJ - CD Player	G-Tour-CD-13x17	G-Tour-CDMX13x17			
AMERICAN AUDIO	CDI 500 MP3	Pro DJ - CD Player	G-Tour-CD-13x17	G-Tour-CDMX13x17			
AMERICAN AUDIO	CDS-1	Pro DJ - CD Player	G-Tour-CD-9x12	G-Tour-CDMX9x12			
AMERICAN AUDIO	CK-1000	Pro DJ - Mixer	G-MIX 17 x 18	GMC-2222	G-Tour-T-Table		
AMERICAN AUDIO	CK-800	Pro DJ - Mixer	G-MIX 17 x 18	GMC-2222	G-Tour-T-Table		
AMERICAN AUDIO	DLS-15	Speaker	GPA-700	GPA-777			
AMERICAN AUDIO	DLS-15P	Speaker	GPA-700	GPA-777			
AMERICAN AUDIO	HTD 4.5	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
AMERICAN AUDIO	MX-1400	Pro DJ - Mixer	G-MIX-B 1515	G-MIX-L 1618	G-MIX 17 x 18	GMC-2222	G-Tour-CDMX13x17
AMERICAN AUDIO	PSW-15	Speaker - Sub	G-Sub-2225-24 Bag				
AMERICAN AUDIO	PSW-15P	Speaker - Sub	G-Sub-2225-24 Bag				
AMERICAN AUDIO	PXI-10P	Speaker	GPA-600				
AMERICAN AUDIO	PXI-12P	Speaker	GPA-700	GPA-600	GPA-777		
AMERICAN AUDIO	PXI-15P	Speaker	GPA-700	GPA-777			
AMERICAN AUDIO	Q-221	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CDMX9x12		
AMERICAN AUDIO	Q-2221/SX	Pro DJ - Turntable	G-Tour-CDMX9x12				
AMERICAN AUDIO	Q-2221/X	Pro DJ - Turntable	G-Tour-CDMX9x12				
AMERICAN AUDIO	Q-D1	Pro DJ - Mixer	G-Tour-CD-9x12	G-Tour-CDMX9x12			
AMERICAN AUDIO	Q-D1 MKII	Pro DJ - Mixer	G-Tour-CD-9x12	G-Tour-CDMX9x12			
AMERICAN AUDIO	Q-D3	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CDMX9x12		
AMERICAN AUDIO	Q-D5	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CDMX9x12		
AMERICAN AUDIO	Q-D5 MKII	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CDMX9x12		
AMERICAN AUDIO	Q-D5B	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CDMX9x12		
AMERICAN AUDIO	Q-D6	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CDMX9x12		
AMERICAN AUDIO	Q-MX2BPM	Pro DJ - Mixer	G-MIX-B 1212	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	G-Tour-CDMX9x12
AMERICAN AUDIO	TTD-2500MKII	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
AMERICAN AUDIO	XDM-221	Pro DJ - Mixer	G-Tour-CD-9x12	G-Tour-CDMX9x12			
AMERICAN AUDIO	XDM-241	Pro DJ - Mixer	G-Tour-CD-9x12	G-Tour-CDMX9x12			
AMPEG	BA600	Combo Amp 1x15	G-Tour 4x12				
APPLE	20 CINEMA DISPLAY	LCD/Plasma	G-MIX-L 1822	G-TourLCDP2023			
APPLE	M7649ZM/B	LCD/Plasma	G-MIX-L 1822				
APPLE	M8893ZM/A	LCD/Plasma	G-MIX-L 1822	G-TourLCDP2023			
APPLE	MACBOOK 13"	Laptop	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
APPLE	MACBOOK PRO 15"	Laptop	GAV-DLX-20	GK-LT25W	G-TourCarryOnPL	GRC-STUDIO-2-GC	GAV-1813R
APPLE	MACBOOK PRO 17"	Laptop	GK-LT25W	GSR-2U AV	GSRW-2U AV	GRC-STUDIO-2-GC	GAV-1813R
ASK	C110	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO		
ASK	C440	Projector	G-TourCarryOnFO				
ASK	C450	Projector	G-TourCarryOnFO				
AUDIO TECHNICA	ATMX341A	Mixer	G-MIX-B 1212				
AUDIO TECHNICA	ATPL120	Pro DJ - Turntable	GDJ-2500	G-Tour-T-Table			
AUDIO-TECHNICA	ATM351	Mixer	G-TOUR 12X17				
B-52	AT-100	Amp Head	G-TOUR-AMP HEAD				
B-52	AT112	Combo Amp 1x12	G-112A	G-TOUR 2226			
B-52	AT212	Combo Amp 2x12	G-TOUR-AMP HEAD				
B-52	LG10012S	Combo Amp 2x12	G-212A	G-TOUR 2430			
B-52	LG7512	Combo Amp 1x12	G-112A	G-212A	G-TOUR 2226	G-TOUR 2430	
B-52	ST6012	Combo Amp 2x12	G-212A	G-TOUR 2430			
B52	LG-100A	Amp Head	G-901				
B52	LG200AS	Amp Head	G-901	G-TOUR-AMP HEAD			
B52	ST-100A	Amp Head	G-TOUR-AMP HEAD				
B52	ST60A	Amp Head	G-TOUR-AMP HEAD				
BEHRINGER	B1220 PRO	Speaker	GPA-700	GPA-777			
BEHRINGER	B1800X	Speaker - Sub	G-Sub-2225-24 Bag				
BEHRINGER	B212	Speaker	GPA-600				
BEHRINGER	B212A	Speaker	GPA-600				
BEHRINGER	B215	Speaker	GPA-700	GPA-777			
BEHRINGER	B215A	Speaker	GPA-700	GPA-777			
BEHRINGER	BCD2000	Pro DJ - Mixer	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	G-Tour-CDMX13x17
BEHRINGER	BCF2000	Digital Interface	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	
BEHRINGER	BCR2000	Recording Interface	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	GK-LT25W
BEHRINGER	BEDDX3216	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	G-TOUR 20 x 30	GMC-3333	
BEHRINGER	DDX3216	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	G-TOUR 20 x 30	GMC-3333	
BEHRINGER	DJX400	Pro DJ - Mixer	G-Tour-CD-9x12	G-Tour-CDMX9x12	GDJ-DJ Case	G-TOUR 12X17	
BEHRINGER	DJX700	Pro DJ - Mixer	G-MIX-B 1515	G-MIX 17 x 18	GMC-2222		
BEHRINGER	DX052	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222			
BEHRINGER	DX-626	Pro DJ - Mixer	G-MIX-B 1212	G-TOUR 12X17	GMC-2222	G-Tour-CDMX9x12	
BEHRINGER	E1220	Speaker	GPA-700	GPA-777			
BEHRINGER	E1800X	Speaker - Sub	G-Sub-2225-24 Bag				
BEHRINGER	K1800FX	Keyboard Amp	G-112A				
BEHRINGER	K900FX	Keyboard Amp	G-112A				
BEHRINGER	KX1200	Combo Amp 1x15	G-TOUR-AMP HEAD				
BEHRINGER	LC2412	Lighting Controller	G-Tour-T-Table				

Gator Cases Master Cross Reference
Updated 9/19/07

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
BEHRINGER	LX112	Combo Amp 1x12	G-112A	G-212A	G-TOUR 2226	G-TOUR 2430	
BEHRINGER	MX1604A	Mixer	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	
BEHRINGER	MX1804X	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
BEHRINGER	MX2004A	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
BEHRINGER	MX2442A	Mixer	G-MIX 20 x 30	G-MIX 24 x 36	G-TOUR 20 x 30	G-TOUR 24 x 36	GMC-3333
BEHRINGER	MX3282A	Mixer	G-MIX 22 x 46	GMC-4221			
BEHRINGER	MX802A	Mixer	G-MIX-B 1212				
BEHRINGER	MXB1002	Mixer	G-MIX-B 1212	G-TOUR 12X17			
BEHRINGER	PMH1000	Powered Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
BEHRINGER	PMH2000	Powered Mixer	GPA-720	GMC-2222			
BEHRINGER	PMH3000	Powered Mixer	G-MIX-B 2020	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222
BEHRINGER	PMH5000	Powered Mixer	G-MIX 20 x 25	G-MIX 20 x 30	G-TOUR 20 x 25	G-TOUR 20 x 30	GMC-3333
BEHRINGER	PMH518M	Mixer	G-MIX-L 1224				
BEHRINGER	PMH660M	Powered Mixer	GMC-2222				
BEHRINGER	PMH880S	Powered Mixer	GMC-2222				
BEHRINGER	PMP1000	Powered Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
BEHRINGER	PMP2000	Powered Mixer	GPA-720	GMC-2222			
BEHRINGER	PMP3000	Powered Mixer	G-MIX-B 2020	G-MIX 19X21	G-TOUR 19X21	GMC-2222	
BEHRINGER	PMP5000	Powered Mixer	G-MIX 20 x 25	G-MIX 20 x 30	G-TOUR 20 x 25	G-TOUR 20 x 30	GMC-3333
BEHRINGER	PMX 2000	Powered Mixer	GPA-720	GMC-2222			
BEHRINGER	SL2442FX-PRO	Mixer	G-MIX 20 x 30	G-TOUR 20 x 30	GMC-3333	GMC-4221	
BEHRINGER	SL3242FX-PRO	Mixer	GMC-4221				
BEHRINGER	TRUTH B2029A	Studio Monitor	GMC-3333				
BEHRINGER	UB1622FX-PRO	Mixer	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	
BEHRINGER	UB1832FX-PRO	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
BEHRINGER	UB2442FX-PRO	Mixer	G-MIX-B 1818	G-MIX-L 1822	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
BEHRINGER	UBB1002	Mixer	G-MIX-B 1212	G-TOUR 12X17			
BEHRINGER	ULTRACOUSTIC ACX1800	Combo Amp	G-112A	G-TOUR 2226			
BEHRINGER	ULTRACOUSTIC ACX900	Combo Amp	G-112A	G-TOUR 2226			
BEHRINGER	ULTRASTACK BG412F	Guitar Speaker Cab	G-Tour 4x12				
BEHRINGER	ULTRASTACK BG412H	Guitar Speaker Cab	G-Tour 4x12				
BEHRINGER	ULTRASTACK BG412S	Guitar Speaker Cab	G-Tour 4x12				
BEHRINGER	V-AMPIRE LX1200H	Amp Head	G-901				
BEHRINGER	VMX100	Pro DJ - Mixer	G-MIX-B 1212	G-Tour-CD-9x12	G-Tour-CDMX9x12	GDJ-i-GO	
BEHRINGER	VMX1000	Pro DJ - Mixer	G-MIX-L 1224	G-MIX 12 x24			
BEHRINGER	VMX200	Pro DJ - Mixer	G-MIX-B 1212	G-TOUR 12X17	G-Tour-CD-9x12	G-Tour-CDMX9x12	GDJ-DJ Case
BEHRINGER	VMX300	Pro DJ - Mixer	G-Tour-CD-13x17	G-Tour-CDMX13x17	G-TOUR 12X17		
BEHRINGER	V-TONE GMX1200H	Amp Head	G-901	G-TOUR-AMP HEAD			
BEHRINGER	V-TONE GMX210	Combo Amp 2x10	G-112A	G-212A	G-TOUR 2226	G-TOUR 2430	
BEHRINGER	V-TONE GMX212	Combo Amp 2x12	G-212A	G-TOUR 2430			
BEHRINGER	XENYX 1202	Mixer	G-MIX-B 1212				
BEHRINGER	XENYX 1202 FX	Mixer	G-MIX-B 1212				
BEHRINGER	XENYX 1204	Mixer	G-TOUR 12X17				
BEHRINGER	XENYX 1204FX	Mixer	G-TOUR 12X17				
BEHRINGER	XENYX 1222 FX	Mixer	G-MIX-B 1515	G-MIX 17 x 18	GMC-2222		
BEHRINGER	XENYX 1622 FX	Mixer	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	
BEHRINGER	XENYX 1832 FX	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
BEHRINGER	XENYX 2222FX	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
BEHRINGER	XENYX 2442 FX	Mixer	G-MIX-B 1818	G-MIX-L 1822	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
BEN Q	FP-202W	LCD/Plasma	G-MIX-L 1822	G-TourLCDP2023			
BENCHMARK	DAC1C	Digital Interface	G-MIX-B 1212				
BENQ	PB6100	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
BENQ	PB6200	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
BENQ	PB7110	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
BENQ	PB7200	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
BENQ	PB7210	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
BENQ	PB7230	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
BENQ	PB8220	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
BENQ	PE5120	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
BENQ	PE7700	Projector	G-TourCarryOnFO				
BENQ	PE7800	Projector	G-TourCarryOnFO				
BENQ	PE8700	Projector	G-TourCarryOnFO				
BENQ / ACER	859	LCD/Plasma	G-TourLCDP3743				
BLUE SKY	SUB12	Studio Monitor	GMC-2222				
BLUE SKY	SUB8	Studio Monitor	GPA-720	GMC-2222			
BOSE	B1	Speaker - Sub	GPA-600				
BOSS	AD-8	Guitar Multi-Effects	G-MIX-B 1212				
BOSS	BR1180CD	Recording Workstation	G-MIX-L 1224	G-MIX 12 x24	GMC-2222		
BOSS	BR1200CD	Recording Workstation	G-MIX-L 1224	G-MIX 12 x24	GMC-2222		
BOSS	BR1600CD	Recording Workstation	G-MIX-L 1622	G-MIX 19X21	G-TOUR 19X21	GMC-2222	
BOSS	BR-864	Recording Workstation	G-TOUR 12X17				
BOSS	BR-900CD	Recording Workstation	G-TOUR 12X17				
BOSS	DR. 880	Drum Machine	G-MIX-B 1212				
BOSS	GS-10	Guitar Multi-Effects	G-TOUR 12 x 17				
BOSS	GT-6	Guitar Multi-Effects	GK-2110	G-MIX 12 x24			
BOSS	GT-6B	Guitar Multi-Effects	GK-2110	G-MIX 12 x24			
BOSS	GT-8	Guitar Multi-Effects	GK-2110	G-MIX 12 x24			
BOSS	ME-50	Guitar Multi-Effects	G-TOUR 12 x 17				
BOSS	ME-50B	Guitar Multi-Effects	G-TOUR 12 x 17				
BOSS	SP-505	Sequencer	G-MIX-B 1212	G-TOUR 12X17	GMC-2222		
BOXLIGHT	7200	LCD/Plasma	G-TourLCDP3743				
BUDDA	SUPERDRIVE 18	Combo Amp	G-TOUR 2226				
CANNON	LV-S3	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
CANON	LV-5220	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
CANON	LV-7220	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
CANON	LV-7225	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
CANON	LV-7230	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
CANON	LV-S4	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
CANON	LV-X4	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
CANON	REALIS SX-50	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	G-TourCarryOnFO	
CASIO	140	Keyboard	GKB-88	GK-88 Slim	GK-288R	GK-288 Slim	G-Tour 88 Slim
CASIO	140S	Keyboard	GKB-88	GK-88 Slim	GK-288R	GK-288 Slim	G-Tour 88 Slim
CASIO	CTK-496	Keyboard	GKB-49	GK-49	GKC-1540		
CASIO	CTK-691	Keyboard	GKC-1540				
CASIO	CTK-700	Keyboard	GKC-1540				
CASIO	CTK710	Keyboard	GKB-49	GK-49	GKC-1540		
CASIO	CTK800	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
CASIO	CTK810	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
CASIO	CTK900	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
CASIO	LK100	Keyboard	GKB-49	GK-49	GK-4212	GKC-1540	
CASIO	LK-200S	Keyboard	GKB-49	GK-49	GKC-1540		
CASIO	LK-300TV	Keyboard	GKC-1540				
CASIO	LK94	Keyboard	GKC-1540				
CASIO	P70	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	
CASIO	P70S	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	
CASIO	PS20	Keyboard	GKB-88 Slim	GK-88 Slim	GK-288R	GK-288 Slim	G-Tour 88 Slim
CASIO	PX-100	Keyboard	GKB-88 Slim	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim	
CASIO	PX110	Keyboard	GKB-88 Slim	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim	
CASIO	PX-200	Keyboard	GKB-88 Slim	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim	
CASIO	PX-300	Keyboard	GKB-88 Slim	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim	
CASIO	PX310	Keyboard	GKC-1648				
CASIO	PX500L	Keyboard	GKB-88 Slim	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim	
CASIO	PX575R	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	
CASIO	WK-1300	Keyboard	GKC-1648				
CASIO	WK-3000	Keyboard	GKC-1540				
CASIO	WK3200	Keyboard	GKC-1648				
CASIO	WK-3300	Keyboard	GKC-1648				
CASIO	WK-3500	Keyboard	GKC-1540				
CASIO	WK3700	Keyboard	GKC-1648				
CASIO	WK-3800	Keyboard	GKC-1648				
CASIO	WK8000	Keyboard	GKC-1648				
CASIO	XJ-560	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
CASIO	YPG-225	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	GKC-1648
CASIO	YPG-525	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	GKC-1648
CASIO	YPG-625	Keyboard	GK-288R	G-Tour 88	GKC-1648		
CERWIN VEGA	CVA-118	Speaker - Sub	G-Sub-2225-24 Bag				
CERWIN VEGA	HT2510	Speaker - Sub	GPA-600				
CERWIN VEGA	LW10	Speaker - Sub	GPA-600				
CERWIN VEGA	PSX-36	Speaker - Sub	G-Sub-2225-24 Bag				
CHAMPION	42CV1	LCD/Plasma	G-TourLCDP3743				
CLAVIA	G2X	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
CLAVIA	NORD ELECTRO 2 61	Keyboard	GKB-49	GK-49	GK-4212	GKC-1540	
CLAVIA	NORD ELECTRO 2 73	Keyboard	GK-261R	G-Tour 61	GKC-1540		
CLAVIA	NORD ELECTRO 61	Keyboard	GKB-49	GK-49	GK-4212	GKC-1540	
CLAVIA	NORD ELECTRO 73	Keyboard	GK-261R	G-Tour 61	GKC-1540		
CLAVIA	NORD LEAD 2	Keyboard	GKB-49	GK-49			
CLAVIA	NORD LEAD 2X	Keyboard	GKB-49	GK-49	GK-4212		
CLAVIA	NORD LEAD 3	Keyboard	GKB-49	GK-49	GK-4212		
CLAVIA	NORD MODULAR G2X	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
CLAVIA	NORD STAGE 73	Keyboard	GKC-1540				
CLAVIA	NORD STAGE 76	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	GKC-1540
CLAVIA	NORD STAGE 88	Keyboard	GKB-88 Slim	GK-88 Slim	GK-288R	GK-288 Slim	G-Tour 88 Slim
CME	UF5	Keyboard	GKB-49	GK-49			
CME	UF50	Keyboard	GKB-49	GK-49			
CME	UF6	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
CME	UF60	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
CME	UF7	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	
CME	UF70	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	
CME	UF8	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	
CME	UF80	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	
CME	VX5	Recording Interface	GKB-49	GK-49	GMC-4221		
CME	VX6	Recording Interface	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
CME	VX7	Recording Interface	GKB-76	GK-76	GK-276R	G-Tour 76	
CME	VX8	Recording Interface	GKB-88	GK-88	GK-288R	G-Tour 88	
COMMUNITY	SBS12	Speaker - Sub	GPA-777				
COOPER SOUND	SYSTEM 6	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
COOPER SOUND	SYSTEM 8	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
CORTEX	DMIX-300	Pro DJ - Mixer	G-MIX-L 1224	G-MIX 12 x24	GMC-2222		
CORTEX	DMIX-600	Pro DJ - Mixer	G-MIX-L 1224	G-MIX 12 x24	GMC-2222		
CRATE	BV120HB	Amp Head	G-TOUR-AMP HEAD				
CRATE	BV150HB	Amp Head	G-901	G-TOUR-AMP HEAD			
CRATE	BV215S	Guitar Speaker Cab	G-Tour 4x12				
CRATE	BV300HB	Amp Head	G-TOUR-AMP HEAD				
CRATE	BV412RVB	Guitar Speaker Cab	G-Tour 4x12				
CRATE	BV412SL	Guitar Speaker Cab	G-Tour 4x12				
CRATE	BV412ST	Guitar Speaker Cab	G-Tour 4x12				
CRATE	BV412SVB	Guitar Speaker Cab	G-Tour 4x12				
CRATE	CA125DG	Combo Amp 2x10	G-112A	G-TOUR 2226			
CRATE	CSX-12	Mixer	GMC-3333				
CRATE	CSX-16	Mixer	G-MIX 24 x 36	G-TOUR 24 x 36	GMC-3333	GMC-4221	
CRATE	FW120	Combo Amp 2x12	G-TOUR 2430				
CRATE	FW120H	Amp Head	G-901	G-TOUR-AMP HEAD			
CRATE	FW412A	Guitar Speaker Cab	G-Tour 4x12				
CRATE	FW412B	Guitar Speaker Cab	G-Tour 4x12				

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
CRATE	GLX1200H	Amp Head	G-901				
CRATE	GLX212	Combo Amp 2x12	G-TOUR 2430				
CRATE	GLX412SL	Guitar Speaker Cab	G-Tour 4x12				
CRATE	GLX412ST	Guitar Speaker Cab	G-Tour 4x12				
CRATE	GLX50	Combo Amp 1x12	G-112A				
CRATE	GLX65	Combo Amp 1x12	G-TOUR 2226				
CRATE	GT112SL	Guitar Speaker Cab	G-212A	G-TOUR 2430			
CRATE	GT1200H	Amp Head	G-901	G-TOUR-AMP HEAD			
CRATE	GT212	Combo Amp 2x12	G-212A	G-TOUR 2430			
CRATE	GT30	Combo Amp	G-112A				
CRATE	GT3500H	Amp Head	G-901	G-TOUR-AMP HEAD			
CRATE	GT412SL	Guitar Speaker Cab	G-Tour 4x12				
CRATE	GT65	Combo Amp 1x12	G-112A	G-TOUR 2226			
CRATE	GTX212	Combo Amp 2x12	G-212A	G-TOUR 2430			
CRATE	GTX65	Combo Amp 1x12	G-112A	G-TOUR 2226			
CRATE	PA8FX	Powered Mixer	GMC-2222				
CRATE	PX700DLX	Powered Mixer	GPA-720	GMC-2222			
CRATE	V212T	Combo Amp 2x12	G-212A	G-TOUR 2430			
CRATE	V3112	Combo Amp 1x12	G-112A	G-TOUR 2226			
CRATE	VFX5112	Combo Amp 1x12	G-112A	G-TOUR 2226			
CRATE	VFX5212	Combo Amp 2x12	G-212A	G-TOUR 2430			
CRATE	VTX200S	Combo Amp 2x12	G-212A	G-TOUR 2430			
CRATE	VTX212B	Combo Amp 2x12	G-212A	G-TOUR 2430			
CRATE	VTX350 HEAD	Amp Head	G-901	G-TOUR-AMP HEAD			
CRATE	VTX65B	Combo Amp 1x12	G-112A	G-TOUR 2226			
CRATE	XT120R	Combo Amp 2x12	G-212A	G-TOUR 2430			
CREATIVE-LABS	PROKEYS PD-MIDI	Keyboard	GK-2110	GK-LT25W			
CREST	LQ15	Speaker	G-Sub-2225-24 Bag				
CREST	LQ15P	Speaker	G-Sub-2225-24 Bag				
CREST AUDIO	XR20	Mixer	G-MIX-B 2020	G-MIX-L 1822	G-MIX 19X21	G-TOUR 19X21	GMC-2222
CREST AUDIO	XR24	Mixer	G-MIX-B 2020	G-MIX-L 1822	G-MIX 19X21	G-TOUR 19X21	GMC-2222
CREST AUDIO	XRM	Mixer	G-MIX-B 2020	G-MIX-L 1822	G-MIX 19X21	G-TOUR 19X21	GMC-2222
DAEWOO	DP-42SM	LCD/Plasma	G-TourLCDP3743				
DAEWOO	PPM-42S3	LCD/Plasma	G-TourLCDP3743				
DAVE SMITH	POLY EVOLVER KEYBOARD	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
DELL	2007 WFP	LCD/Plasma	G-TourLCDP2023				
DELL	INSPIRON 1200	Laptop	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	G-TourCarryOnPL	GRC-STUDIO-2-GO
DELL	INSPIRON 1300	Laptop	GAV-DLX-20	GK-LT25W	G-TourCarryOnPL	GRC-STUDIO-2-GC	GAV-1813R
DELL	INSPIRON 6000	Laptop	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GK-LT25W	G-TourCarryOnPL
DELL	INSPIRON 9400	Laptop	GK-LT25W	GSR-2U AV	GSRW-2U AV	GRC-STUDIO-2-GC	GAV-1813R
DELL	INSPIRON B120	Laptop	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GK-LT25W	G-TourCarryOnPL
DELL	INSPIRON E1505	Laptop	GAV-DLX-20	GK-LT25W	G-TourCarryOnPL	GRC-STUDIO-2-GC	GAV-1813R
DELL	INSPIRON E1705	Laptop	GK-LT25W	GSR-2U AV	GSRW-2U AV	GRC-STUDIO-2-GC	GAV-1813R
DELL	LATITUDE C610	Laptop	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
DELL	W4200	LCD/Plasma	G-TourLCDP3743				
DELL	XPS M1210	Laptop	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
DELL	XPS M1710	Laptop	GK-LT25W	GSR-2U AV	GSRW-2U AV	GRC-STUDIO-2-GC	GAV-1813R
DELPHI	DD42 EVOLUTION	LCD/Plasma	G-TourLCDP3743				
DELPHI	PRO42 EVOLUTION	LCD/Plasma	G-TourLCDP3743				
DENON	DN-S1000	Pro DJ - CD Player	G-Tour-CD-9x12	G-Tour-CDMX9x12			
DENON	DN-X100	Pro DJ - Mixer	G-MIX-B 1212	G-Tour-CD-9x12	G-Tour-CDMX9x12		
DENON	DN-X1500	Pro DJ - Mixer	G-MIX-B 1515	G-MIX 17 x 18	GMC-2222		
DENON	DN-X300	Pro DJ - Mixer	G-TOUR 12X17				
DENON	DP29F	Pro DJ - Turntable	GDJ-2500				
DENON	DP300F	Pro DJ - Turntable	GDJ-1500	GDJ-2500			
DIGIDESIGN	COMMAND 8	Mixer	G-MIX-B 1818	G-MIX-L 1822	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
DIGIDESIGN	DIGI002	Mixer	G-MIX-L 1822	G-MIX 19X21	G-TOUR 19X21	GMC-2222	
DIGIDESIGN	DIGI-003	Mixer	G-MIX-B 2020	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222	
DIGIDESIGN	MBOX2	Digital Interface	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-3333		
DIGITECH	GNX1	Guitar Multi-Effects	G-TOUR 12 x 17				
DIGITECH	GNX2	Guitar Multi-Effects	GK-2110				
DIGITECH	GNX3	Guitar Multi-Effects	GK-2110	G-MIX 12 x24			
DIGITECH	GNX3000	Guitar Multi-Effects	GK-2110				
DIGITECH	GNX4	Guitar Multi-Effects	GK-2110	G-MIX 12 x24			
DIGITECH	VOCAL 300	Guitar Multi-Effects	G-TOUR 12 x 17				
DYNACORD	PM 1000	Mixer	GMC-2222				
DYNAUDIO	BM12A	Studio Monitor	GPA-720	GMC-2222			
DYNAUDIO	BM14S	Studio Monitor	GMC-2222				
DYNAUDIO	BM6A MKII	Studio Monitor	GMC-2222				
DYNAUDIO	BM9S	Studio Monitor	GMC-2222				
EAW	FR129Z	Speaker	GPA-600	GPA-777			
EAW	SB120ZP	Speaker - Sub	GPA-600				
EAW	SM109Z	Speaker	GPA-600				
EAW	SM129Z	Speaker	GPA-700				
EAW	SM159Z	Speaker	G-Sub-2225-24 Bag				
EDIROL	M-100FX	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17	GMC-2222	
EDIROL	M10DX	Mixer	G-MIX-B 1212				
EDIROL	M16DX	Mixer	G-TOUR 12X17				
EDIROL	PCR-1	Keyboard	GK-2110	GK-LT25W			
EDIROL	PCR300	Keyboard	GK-LT25W				
EDIROL	PCR500	Keyboard	GKB-49	GK-49			
EDIROL	PCR800	Keyboard	GK-4212				
EDIROL	PCR-A30	Keyboard	GK-LT25W				
EDIROL	PCR-M1	Keyboard	GK-2110	GK-LT25W			
EDIROL	PCR-M30	Keyboard	GK-LT25W				
EDIROL	PCR-M50	Keyboard	GKB-49	GK-49			
EDIROL	PCR-M80	Keyboard	GK-4212				

Gator Cases Master Cross Reference
Updated 9/19/07

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
EDIROL	UM-550	Digital Interface	G-MIX-B 1212	G-TOUR 12X17			
EDIROL	UR-80	Digital Interface	G-TOUR 12X17				
EDIROL	V-4	Mixer	G-MIX-B 1212	G-TOUR 12X17			
EIKI	LC-XB28	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
EIKI	PLD-42UE	LCD/Plasma	G-TourLCDP3743				
EIKI	PLD-42XU	LCD/Plasma	G-TourLCDP3743				
EIZO	CE210W	LCD/Plasma	G-MIX-L 1622	G-TourLCDP2023			
EIZO	CE240W	LCD/Plasma	G-TourLCDP2023				
EIZO	CG19	LCD/Plasma	G-MIX-L 1618	G-MIX-L 1622			
EIZO	CG210	LCD/Plasma	G-MIX-L 1622	G-MIX-L 1822	G-TourLCDP2023		
EIZO	P5070	LCD/Plasma	G-TourLCDP50				
EIZO	P5071	LCD/Plasma	G-TourLCDP50				
EIZO	S2000	LCD/Plasma	G-MIX-L 1618	G-MIX-L 1622			
ELECTRO VOICE	ELIMINATOR MONITOR	Speaker	GPA-700				
ELECTRO VOICE	FORCE I 12"	Speaker	GPA-600				
ELECTRO VOICE	SB112	Studio Monitor	GPA-700	GPA-600	GPA-777	GMC-3333	
ELECTRO VOICE	SBA760	Speaker - Sub	G-Sub-2225-24 Bag				
ELECTRO VOICE	SX100	Speaker	GPA-700	GPA-600	GPA-777		
ELECTRO VOICE	SX250	Speaker	GPA-700	GPA-777			
ELECTROGRAPH	DTS42DD	LCD/Plasma	G-TourLCDP3743				
ELECTROGRAPH	E4203DD	LCD/Plasma	G-TourLCDP3743				
EMES	AMBER	Studio Monitor	GPA-600	GMC-2222			
EMES	AMBER HR	Studio Monitor	GMC-2222				
E-MU	X BOARD 61	Keyboard	GKB-49	GK-49	GK-4212		
E-MU	XBOARD 25	Keyboard	GK-2110	GK-LT25W			
E-MU	XBOARD 49	Keyboard	GKB-49	GK-49			
EMU	0404 USB	Digital Interface	G-MIX-B 1212	G-TOUR 12X17			
ENVISION	A42W64	LCD/Plasma	G-TourLCDP3743				
EPIPHONE	BLUES CUSTOM 30	Combo Amp 2x12	G-212A	G-TOUR 2430			
EPIPHONE	SO CAL	Amp Head	G-TOUR-AMP HEAD				
EPIPHONE	SO CAL 412SL	Guitar Speaker Cab	G-Tour 4x12				
EPSON	730	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO	G-TourCarryOnPL	
EPSON	760	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO	G-TourCarryOnPL	
EPSON	61P	Projector	G-TourCarryOnFO				
EPSON	730C	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO	G-TourCarryOnPL	
EPSON	73C	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-1813R	G-TourCarryOnPL
EPSON	81P	Projector	G-TourCarryOnFO				
EPSON	820P	Projector	G-TourCarryOnFO				
EPSON	821P	Projector	G-TourCarryOnFO				
EPSON	830P	Projector	G-TourCarryOnFO				
EPSON	835P	Projector	G-TourCarryOnFO				
EPSON	POWERLITE 732C	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnPL		
EPSON	POWERLITE 737C	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnPL		
EPSON	POWERLITE 740C	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnPL		
EPSON	POWERLITE 745C	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnPL		
EPSON	S1	Projector	G-TourCarryOnFO				
EPSON	S3	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-1813R	G-TourCarryOnPL
EVENT	S100SUB	Studio Monitor	GPA-720	GMC-2222			
FBT	JOLLY12RA	Speaker	GPA-700	GPA-777			
FBT	MAXX 2	Speaker	GPA-600	GPA-777			
FBT	MAXX 4	Speaker	GPA-700	GPA-777			
FENDER	57 AMP LTD	Combo Amp 1x12	G-112A	G-TOUR 2226			
FENDER	57 DELUXE	Combo Amp 1x12	G-112A	G-TOUR 2226			
FENDER	57 TWIN	Combo Amp 2x12	G-212A	G-TOUR 2226	G-TOUR 2430		
FENDER	65 DELUXE REVERB	Combo Amp 1x12	G-112A	G-212A	G-TOUR 2226		
FENDER	65 TWIN REVERB	Combo Amp 2x12	G-212A	G-TOUR 2430			
FENDER	ACOUSTASONIC JR.	Combo Amp 1x12	G-112A	G-TOUR 2226			
FENDER	BASSMAN 300	Amp Head	G-TOUR 2226				
FENDER	BLONDE HOT ROD DELUXE	Combo Amp 1x12	G-112A	G-TOUR 2226			
FENDER	BLUES DELUXE	Combo Amp 1x12	G-112A	G-TOUR 2226			
FENDER	CYBER TWIN	Combo Amp 2x12	G-TOUR 2430				
FENDER	DELUXE 900	Combo Amp 1x12	G-112A	G-TOUR 2226			
FENDER	DUAL PROFESSIONAL	Combo Amp 2x12	G-212A	G-TOUR 2430			
FENDER	FM 100H	Amp Head	G-901				
FENDER	FM 212R	Combo Amp 2x12	G-212A	G-TOUR 2226	G-TOUR 2430		
FENDER	FM210R	Combo Amp 2x10	G-112A				
FENDER	FM212 DSP	Combo Amp 2x12	G-212A	G-TOUR 2430			
FENDER	FM412 SL	Guitar Speaker Cab	G-Tour 4x12				
FENDER	HOT ROD DELUXE	Combo Amp 1x12	G-112A	G-TOUR 2226			
FENDER	HOT ROD DEVILLE 212	Combo Amp 2x12	G-212A	G-TOUR 2226	G-TOUR 2430		
FENDER	MH-412	Guitar Speaker Cab	G-Tour 4x12				
FENDER	MH500	Amp Head	G-901	G-TOUR-AMP HEAD			
FENDER	PROSONIC 412	Guitar Speaker Cab	G-Tour 4x12				
FENDER	PROSONIC HEAD	Amp Head	G-901				
FENDER	ROC PRO 700	Combo Amp 1x12	G-112A	G-TOUR 2226			
FENDER	STAGE 1000	Combo Amp 1x12	G-112A	G-TOUR 2226			
FENDER	STAGE 1600	Combo Amp 2x12	G-212A	G-TOUR 2430			
FENDER	SUPER SONIC HEAD	Amp Head	G-901				
FENDER	SUPER-SONIC 112	Combo Amp 1x12	G-212A	G-TOUR 2226			
FENDER	SUPER-SONIC 412	Guitar Speaker Cab	G-Tour 4x12				
FENDER	TONE MASTER 412	Guitar Speaker Cab	G-Tour 4x12				
FENDER	TONE MASTER HEAD	Amp Head	G-901				
FENDER	TWIN AMP	Combo Amp 2x12	G-TOUR 2430				
FENDER	ULTIMATE CHORUS	Combo Amp 2x12	G-212A	G-TOUR 2430			
FENDER	VIBRO KING 212	Combo Amp 2x12	G-212A	G-TOUR 2226	G-TOUR 2430		
FENDER	VIBRO KING 3 10	Combo Amp	G-212A	G-TOUR 2430			
FENDER	VIBROLUX REVERB	Combo Amp 2x10	G-112A	G-212A			

Gator Cases Master Cross Reference

Updated 9/19/07

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
FOSTEX	FR-2	Recording Workstation	G-MIX-B 1212				
FOSTEX	FR2	Media Player	G-MIX-B 1212				
FOSTEX	FR2TC	Media Player	G-MIX-B 1212				
FOSTEX	MR-16HD	Recording Workstation	G-MIX-L 1822	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222
FOSTEX	MR-16HD/CD	Recording Workstation	G-MIX-L 1822	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222
FOSTEX	MR-8	Recording Workstation	G-MIX-B 1212	G-TOUR 12X17			
FOSTEX	MR8 MKII	Recording Workstation	G-MIX-B 1212	G-TOUR 12X17			
FOSTEX	MR-8HD	Recording Workstation	G-TOUR 12X17	GMC-2222			
FOSTEX	MR8HDCD	Recording Workstation	G-TOUR 12X17	GMC-2222			
FOSTEX	VF160	Recording Workstation	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
FOSTEX	VF160EX	Recording Workstation	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
FOSTEX	VF80	Digital Interface	G-TOUR 12X17				
FOSTEX	VF80EX	Recording Workstation	G-TOUR 12X17				
FUJITSU	P42HHA10	LCD/Plasma	G-TourLCDP3743				
FUJITSU	P42VHA10	LCD/Plasma	G-TourLCDP3743				
FUJITSU	P50XHA10	LCD/Plasma	G-TourLCDP50				
FUJITSU	PDS-4201	LCD/Plasma	G-TourLCDP3743				
FUJITSU	PDS-4203	LCD/Plasma	G-TourLCDP3743				
FUJITSU	PDS-4204	LCD/Plasma	G-TourLCDP3743				
FUJITSU	PDS-4207	LCD/Plasma	G-TourLCDP3743				
FUJITSU	PDS-4208	LCD/Plasma	G-TourLCDP3743				
FUJITSU	PDS-4209	LCD/Plasma	G-TourLCDP3743				
FUJITSU	PDS-4210	LCD/Plasma	G-TourLCDP3743				
FUJITSU	PDS-4211	LCD/Plasma	G-TourLCDP3743				
FUJITSU	PDS-4212	LCD/Plasma	G-TourLCDP3743				
FUJITSU	PDS-4213	LCD/Plasma	G-TourLCDP3743				
FUJITSU	PDS-4214	LCD/Plasma	G-TourLCDP3743				
FUJITSU	PDS-4221	LCD/Plasma	G-TourLCDP3743				
FUJITSU	PDS-4222	LCD/Plasma	G-TourLCDP3743				
FUJITSU	PDS-4233	LCD/Plasma	G-TourLCDP3743				
FUJITSU	PDS-5001	LCD/Plasma	G-TourLCDP50				
GATEWAY	42 ED & 42 HD	LCD/Plasma	G-TourLCDP3743				
GATEWAY	50 ED & 50 HD	LCD/Plasma	G-TourLCDP50				
GEMINI	CDJ SERIES	Pro DJ - CD Player	G-Tour-CD-9x12	G-Tour-CDMX9x12	GDJ-DJ Case		
GEMINI	CFX-30	Pro DJ - CD Player	G-Tour-CD-9x12	G-Tour-CDMX9x12	GDJ-DJ Case		
GEMINI	MPX-30	Pro DJ - CD Player	G-Tour-CD-9x12	G-Tour-CDMX9x12	GDJ-DJ Case		
GEMINI	PDM SERIES	Pro DJ - Mixer	G-MIX-L 1224	G-MIX 12 x24			
GEMINI	PMX SERIES	Pro DJ - Mixer	G-MIX-B 1212	GMC-2222	G-Tour-CDMX9x12		
GEMINI	PS SERIES	Pro DJ - Mixer	G-MIX-B 1212	GMC-2222	G-Tour-CDMX9x12		
GEMINI SOUND	GX350	Speaker	GPA-700				
GENELEC	1038B	Studio Monitor	GMC-3333	GMC-4221			
GENELEC	7050B	Studio Monitor	GMC-2222				
GENELEC	7060B	Studio Monitor	GMC-2222				
GENELEC	7070A	Studio Monitor	G-Sub-2225-24 Bag	GMC-3333			
GENELEC	7260A	Studio Monitor	GMC-2222				
GENELEC	7270A	Studio Monitor	G-Sub-2225-24 Bag	GMC-3333			
GENELEC	7271A	Studio Monitor	GMC-3333				
GENELEC	8250A	Studio Monitor	GPA-720	GMC-2222			
HAMMOND	XK-1	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	
HAMMOND	XK2	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	GKC-1648
HAMMOND	XK3	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	GKC-1648
HAMMOND	XM2	Recording Interface	GK-LT25W				
HITACHI	402HDE	LCD/Plasma	G-TourLCDP3743				
HITACHI	402HDU	LCD/Plasma	G-TourLCDP3743				
HITACHI	4120HDU	LCD/Plasma	G-TourLCDP3743				
HITACHI	42PMA500E	LCD/Plasma	G-TourLCDP3743				
HITACHI	CMP4201U	LCD/Plasma	G-TourLCDP3743				
HITACHI	CMP4202U	LCD/Plasma	G-TourLCDP3743				
HITACHI	CMP4211U	LCD/Plasma	G-TourLCDP3743				
HITACHI	CMP-5000	LCD/Plasma	G-TourLCDP50				
HITACHI	CP-RS55	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO	G-TourCarryOnPL	
HITACHI	CP-S235W	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
HITACHI	CP-S318	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
HITACHI	CP-S335	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
HITACHI	CP-S420	Projector	G-TourCarryOnFO				
HITACHI	CP-X275	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
HITACHI	CP-X340	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
HITACHI	CP-X345	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
HITACHI	CP-X430	Projector	G-TourCarryOnFO				
HITACHI	CP-X443	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
HITACHI	CP-X445W	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
HOHNER	3002 ARIETTE	Accordion	GW-ACC-1311	GW-ACC-1514			
HOHNER	CORONA III	Accordion	GW-ACC-1514				
HOHNER	HA-114	Accordion	GW-ACC-1311	GW-ACC-1514			
HOHNER	HA-1600	Accordion	GW-ACC-1311	GW-ACC-1514			
HOHNER	HA-1622	Accordion	GW-ACC-1311	GW-ACC-1514			
HOHNER	HA-2815	Accordion	GW-ACC-1311	GW-ACC-1514			
HOHNER	HA-3000	Accordion	GW-ACC-1311	GW-ACC-1514			
HOHNER	HA-3002	Accordion	GW-ACC-1311	GW-ACC-1514			
HOHNER	HA-3100	Accordion	GW-ACC-1514				
HOHNER	HA-3500	Accordion	GW-ACC-1514				
HOHNER	HA-3522	Accordion	GW-ACC-1514				
HOHNER	HOHNICA 1302	Accordion	GW-ACC-1514				
HOHNER	HOHNICA 2352	Accordion	GW-ACC-1514				
HOHNER	NOVA II 48	Accordion	GW-ACC-1514				
HP	L1506	LCD/Plasma	GAV-1412R	GAV-1813R			
HP	L1740	LCD/Plasma	G-MIX-L 1618				

Gator Cases Master Cross Reference
Updated 9/19/07

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
HP	L1740 W STAND	LCD/Plasma	G-MIX-L 1618				
HP	L1755	LCD/Plasma	GAV-1813R				
HP	L2045W	LCD/Plasma	G-MIX-L 1622	G-TourLCDP2023			
HP	LP1965	LCD/Plasma	G-MIX-L 1618	GAV-1813R			
HP	LP2065	LCD/Plasma	G-MIX-L 1618	G-MIX-L 1622			
HP	LP2465	LCD/Plasma	G-MIX-L 1622	G-MIX-L 1822	G-TourLCDP2023		
HP	LP3065	LCD/Plasma	G-TourLCDP2632				
HUGHES & KETTNER	ALEX LIFESON SIGNATURE	Amp Head	G-TOUR-AMP HEAD				
HUGHES & KETTNER	CC412A	Guitar Speaker Cab	G-Tour 4x12				
HUGHES & KETTNER	DUOTONE	Amp Head	G-TOUR-AMP HEAD				
HUGHES & KETTNER	MATRIX 100	Amp Head	G-901	G-TOUR-AMP HEAD			
HUGHES & KETTNER	PURETONE	Amp Head	G-901				
HUGHES & KETTNER	SWITCHBLADE 100 2X12	Combo Amp 2x12	G-212A	G-TOUR 2226	G-TOUR 2430		
HUGHES & KETTNER	SWITCHBLADE 100 HEAD	Amp Head	G-901	G-TOUR-AMP HEAD			
HUGHES & KETTNER	SWITCHBLADE 50	Combo Amp 1x12	G-112A	G-TOUR 2226			
HUGHES & KETTNER	TRIAMP MKII	Amp Head	G-TOUR-AMP HEAD				
HUGHES & KETTNER	WARP X	Amp Head	G-901				
HYUNDAI	Q321	LCD/Plasma	G-TourLCDP2632				
IBANEZ	IS412C	Guitar Speaker Cab	G-Tour 4x12				
IBANEZ	TB100H	Amp Head	G-901	G-TOUR-AMP HEAD			
IBANEZ	TBX150H	Amp Head	G-901				
IBANEZ	TBX150R	Combo Amp	G-212A	G-TOUR 2430			
IBANEZ	TBX65R	Combo Amp	G-112A				
INFOCUS	IN24	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
INFOCUS	LP 530	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
INFOCUS	LP540	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO		
INFOCUS	LP600	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
INFOCUS	LP640	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO		
INFOCUS	X1A	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO		
INFOCUS	X2	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO		
INFOCUS	X2 1600	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO		
INFOCUS	X3	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO		
INTER-M	A120	Mixer	G-MIX-L 1618	G-MIX-L 1622	G-MIX 17 x 18	GMC-2222	
INTER-M	A60	Mixer	G-MIX-L 1618	G-MIX-L 1622	G-MIX 17 x 18	GMC-2222	
INTER-M	CA 5130D	Mixer	GMC-2222	GMC-3333			
INTER-M	CA 8320	Powered Mixer	GPA-720	GMC-2222			
INTER-M	MX1243	Mixer	G-MIX-L 1622	GMC-2222			
INTER-M	PA1000B	Mixer	G-MIX-B 1212	G-TOUR 12X17	GMC-2222		
INTER-M	PA1000BR	Mixer	G-MIX-B 1212	G-TOUR 12X17	GMC-2222		
INTER-M	PA2000	Mixer	G-MIX-L 1618	G-MIX-L 1622	G-MIX 17 x 18	GMC-2222	
INTER-M	PA4000	Mixer	G-MIX-L 1618	G-MIX 17 x 18	GMC-2222		
INTER-M	PAM120	Pro DJ - Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
INTER-M	PAM60	Pro DJ - Mixer	GDJ-1500	GDJ-2500	G-Tour-T-Table		
INTER-M	PAM60	Pro DJ - Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
INTER-M	PMC-05 PRO D	Mixer	G-TOUR 12X17	GMC-2222			
INTER-M	RMX1426	Mixer	G-MIX-L 1622	GMC-2222			
INTER-M	SFX 8460	Powered Mixer	GMC-2222				
INTER-M	SMX812	Mixer	G-MIX-B 1212	G-TOUR 12X17			
INTER-M	SYS2240M	Recording Workstation	GPA-720	GMC-2222			
JAMO	C 80 SUB	Speaker - Sub	GPA-600				
JBL	EON10 G2	Speaker	GPA-600				
JBL	JRX112M	Speaker	GPA-700	GPA-600	GPA-777		
JBL	JRX118S	Speaker - Sub	G-Sub-2225-24 Bag				
JBL	LSR4312SP	Studio Monitor	GMC-2222				
JBL	MRX512	Speaker	GPA-777				
JBL	MRX518S	Speaker - Sub	G-Sub-2225-24 Bag				
JBL	PRX512M	Speaker	GPA-777				
JBL	PRX518S	Speaker - Sub	G-Sub-2225-24 Bag				
JBL	SRX712M	Speaker	GPA-600				
JBL	SRX715	Speaker	GPA-700	GPA-777			
JBL	VP7212M	Speaker	GPA-700	GPA-600	GPA-777		
JBL	VRX915M	Speaker	GPA-700	GPA-777			
JBL	VRX928LA	Studio Monitor	GPA-720	GMC-2222			
JBL	VRX932LA	Speaker	GPA-600				
JOHNSON	JM120	Combo Amp 1x12	G-212A	G-TOUR 2430			
JOHNSON	JM150	Combo Amp 2x12	G-212A	G-TOUR 2430			
JOHNSON	JM250H	Amp Head	G-TOUR-AMP HEAD				
JOHNSON	JM60	Combo Amp 1x12	G-112A	G-TOUR 2226			
JOHNSON	JT50	Combo Amp 1x12	G-112A	G-TOUR 2226			
JVC	GD-V4200PZW	LCD/Plasma	G-TourLCDP3743				
JVC	GD-V4210PZW	LCD/Plasma	G-TourLCDP3743				
JVC	GD-V4211PCE	LCD/Plasma	G-TourLCDP3743				
JVC	GD-V425PZW	LCD/Plasma	G-TourLCDP3743				
JVC	GD-V500PZU	LCD/Plasma	G-TourLCDP50				
JVC	GD-V501U	LCD/Plasma	G-TourLCDP50				
JVC	GM-P420UG	LCD/Plasma	G-TourLCDP3743				
JVC	GM-V42UG	LCD/Plasma	G-TourLCDP3743				
KAWAI	MP8	Keyboard	GKC-1648				
KONKA	KDL32AT23U	LCD/Plasma	G-TourLCDP3743				
KORG	AX10A	Guitar Multi-Effects	G-MIX-B 1212				
KORG	AX10B	Guitar Multi-Effects	G-MIX-B 1212				
KORG	AX10G	Guitar Multi-Effects	G-MIX-B 1212				
KORG	AX3000G	Guitar Multi-Effects	GK-2110	G-MIX 12 x24			
KORG	CR-4	Recording Workstation	G-MIX-L 1618	G-MIX-L 1622	G-MIX 17 x 18	GMC-2222	
KORG	CX3	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
KORG	D1200 MKII	Recording Workstation	G-TOUR 12X17	GMC-2222			
KORG	D1600	Recording Workstation	G-MIX-L 1822	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222

Gator Cases Master Cross Reference
 Updated 9/19/07

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
KORG	D1600 MKII	Recording Workstation	G-MIX-L 1822	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222
KORG	D16XD	Recording Workstation	GMC-3333	GMC-4221			
KORG	D3200	Recording Workstation	G-MIX-L 1622	G-MIX-L 1822	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222
KORG	D32XD	Recording Workstation	GMC-3333	GMC-4221			
KORG	D888	Recording Workstation	G-MIX-B 1515	G-MIX-L 1618	G-MIX 17 x 18	GMC-2222	
KORG	EMX1	Recording Workstation	G-TOUR 12X17	GMC-2222			
KORG	ESX1	Recording Workstation	G-TOUR 12X17	GMC-2222			
KORG	K61P	Keyboard	GK-4212				
KORG	KARMA	Keyboard	GKB-76	GK-76	GK-261R	G-Tour 61	GKC-1540
KORG	M3-M + KYBD61	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
KORG	MICROKONTROL	Keyboard	GK-2110	GK-LT25W			
KORG	MICROKORG	Keyboard	GK-2110	GK-LT25W			
KORG	OASYS 88	Keyboard	GKC-1648				
KORG	PA1X	Keyboard	GKC-1540				
KORG	PA1X PRO	Keyboard	GKB-88 Slim	GK-88	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim
KORG	PA1X PRO ELITE	Keyboard	GKB-88 Slim	GK-88 Slim	GK-288R	GK-288 Slim	G-Tour 88 Slim
KORG	PA50	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
KORG	PA80	Keyboard	GKC-1540				
KORG	PA800	Keyboard	GKC-1540				
KORG	PAD-KONTROL	Drum Machine	G-TOUR 12X17				
KORG	R3	Keyboard	GK-LT25W				
KORG	SP-200	Keyboard	GKB-88 Slim	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim	
KORG	SP-250	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	GKC-1648
KORG	SP-300	Keyboard	GKB-88 Slim	GK-88 Slim	GK-288R	GK-288 Slim	G-Tour 88 Slim
KORG	SP-500	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	
KORG	TR61	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
KORG	TR88	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	
KORG	TRITON EXTREME 61	Keyboard	GKB-76	GK-76	GK-261R	G-Tour 61	GKC-1540
KORG	TRITON EXTREME 76	Keyboard	GKB-88 Slim	GK-88 Slim	GK-288R	GK-288 Slim	G-Tour 88 Slim
KORG	TRITON EXTREME 88	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	GKC-1648
KORG	TRITON LE 61	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
KORG	TRITON LE 88	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	
KORG	TRITON STUDIO 61	Keyboard	GKB-76	GK-76	GK-261R	G-Tour 61	GKC-1540
KORG	TRITON STUDIO 88	Keyboard	GK-288R	G-Tour 88	GKC-1648		
KORG	TRITON STUDIO 76	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	GKC-1648
KORG	X50	Keyboard	GK-4212				
KORG	X5D	Keyboard	GKB-49	GK-49	GK-4212		
KORG	ZERO 4	Pro DJ - Mixer	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	G-Tour-CD-13x17	G-Tour-CDMX13x17
KORG	ZERO 8	Pro DJ - Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
KRK	RP10S	Studio Monitor	GMC-2222				
KURZWEIL	K2600	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	GKC-1648
KURZWEIL	K2600S	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	GKC-1648
KURZWEIL	K2600X	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	GKC-1648
KURZWEIL	K2600XS	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	GKC-1648
KURZWEIL	K2661	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
KURZWEIL	PC161	Keyboard	GKB-49	GK-49	GK-4212	GKC-1540	
KURZWEIL	PC1SE	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	
KURZWEIL	PC-1X	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	
KURZWEIL	PC-1XL	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	
KURZWEIL	PC2X	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	
KURZWEIL	PC3	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	
KURZWEIL	SP2	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	
KURZWEIL	SP-88	Keyboard	GKB-88 Slim	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim	
KURZWEIL	SP-88X	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	
KUSTOM	KPC10	Speaker	GPA-600				
KUSTOM	KPC10M	Speaker	GPA-600				
KUSTOM	KPC12	Speaker	GPA-700	GPA-600	GPA-777		
KUSTOM	KPC12M	Speaker	GPA-700	GPA-600	GPA-777		
KUSTOM	KPC15	Speaker	GPA-700				
KUSTOM	KPC15M	Speaker	GPA-700				
KUSTOM	KPM7250T	Mixer	GMC-2222				
KUSTOM	KPM8420	Powered Mixer	GPA-720	GMC-2222			
KUSTOM	KPM8420T	Powered Mixer	GPA-720	GMC-2222			
LG	37LC-7D	LCD/Plasma	G-TourLCDP3743				
LG	50PM1M	LCD/Plasma	G-TourLCDP50				
LG	DU42PX12	LCD/Plasma	G-TourLCDP50				
LG	MU-42PZ11B	LCD/Plasma	G-TourLCDP3743				
LG	MU-42PZ15B	LCD/Plasma	G-TourLCDP3743				
LG	MU50PM10	LCD/Plasma	G-TourLCDP50				
LG	MU60P	LCD/Plasma	G-TourLCDP60				
LG	RU42DX11	LCD/Plasma	G-TourLCDP50				
LINE 6	212S CAB	Guitar Speaker Cab	G-212A	G-TOUR 2430			
LINE 6	412CB	Guitar Speaker Cab	G-Tour 4x12				
LINE 6	412S CAB	Guitar Speaker Cab	G-Tour 4x12				
LINE 6	AX2	Guitar Speaker Cab	G-212A	G-TOUR 2430			
LINE 6	BOD	Guitar Multi-Effects	G-MIX-B 1212				
LINE 6	CLASSIC 112 (FLEX 3)	Combo Amp 1x12	G-212A	G-TOUR 2226	G-TOUR 2430		
LINE 6	CLASSIC 212 (FLEX 3)	Combo Amp 2x12	G-Tour 4x12				
LINE 6	CLASSIC PLUS (FLEX 3)	Combo Amp 1x12	G-212A	G-TOUR 2226	G-TOUR 2430		
LINE 6	DL4	Guitar Multi-Effects	G-MIX-B 1212				
LINE 6	DM4	Guitar Multi-Effects	G-MIX-B 1212				
LINE 6	DUOVERB 212	Combo Amp 2x12	G-212A	G-TOUR 2430			
LINE 6	DUOVERB HEAD	Amp Head	G-901	G-TOUR-AMP HEAD			
LINE 6	EX1	Guitar Multi-Effects	G-MIX-B 1212				
LINE 6	FB4	Guitar Multi-Effects	G-MIX-B 1212				
LINE 6	FBC	Guitar Multi-Effects	GK-2110				
LINE 6	FLEXTONE II	Combo Amp 2x12	G-112A	G-TOUR 2226			

Gator Cases Master Cross Reference
 Updated 9/19/07

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
LINE 6	FLEXTONE II HD	Amp Head	G-901				
LINE 6	FLEXTONE II PLUS	Combo Amp 2x12	G-112A	G-TOUR 2226			
LINE 6	FLEXTONE II XL	Combo Amp 2x12	G-212A	G-TOUR 2430			
LINE 6	FLEXTONE III 112	Guitar Speaker Cab	G-112A	G-212A	G-TOUR 2226	G-TOUR 2430	
LINE 6	FLEXTONE III PLUS 112	Combo Amp 1x12	G-112A	G-212A	G-TOUR 2226	G-TOUR 2430	
LINE 6	FLEXTONE III XL	Combo Amp 2x12	G-212A	G-TOUR 2430			
LINE 6	FM4	Guitar Multi-Effects	G-MIX-B 1212				
LINE 6	HD 147	Amp Head	G-901				
LINE 6	POD 2.0	Guitar Multi-Effects	G-MIX-B 1212				
LINE 6	POD XT (SHARC POD)	Guitar Multi-Effects	G-MIX-B 1212				
LINE 6	POD XT LIVE	Guitar Multi-Effects	GK-2110	G-MIX 12 x24			
LINE 6	SPIDER 212	Combo Amp 2x12	G-212A	G-TOUR 2430			
LINE 6	SPIDER II 112	Combo Amp 1x12	G-112A	G-TOUR 2226			
LINE 6	SPIDER II 210	Combo Amp 2x10	G-112A	G-TOUR 2226			
LINE 6	SPIDER II 212	Combo Amp 2x12	G-901	G-TOUR-AMP HEAD			
LINE 6	SPIDER II 412	Guitar Speaker Cab	G-Tour 4x12				
LINE 6	SPIDER II HD	Amp Head	G-901	G-TOUR-AMP HEAD			
LINE 6	SPIDER II HD75	Amp Head	G-901	G-TOUR-AMP HEAD			
LINE 6	SPIDER III 120	Combo Amp 2x10	G-112A	G-TOUR 2226			
LINE 6	SPIDER III 150	Combo Amp 2x12	G-212A	G-TOUR 2430			
LINE 6	SPIDER III 75	Combo Amp 1x12	G-112A	G-TOUR 2226			
LINE 6	SPIDER III HD150	Amp Head	G-901	G-TOUR-AMP HEAD			
LINE 6	SPIDER III HD75	Amp Head	G-901	G-TOUR-AMP HEAD			
LINE 6	TONEPORT KB37	Keyboard	GK-2110	GK-LT25W			
LINE 6	VETTA HEAD	Amp Head	G-901	G-TOUR-AMP HEAD			
LINE 6	VETTA II CAB	Guitar Speaker Cab	G-Tour 4x12				
LINE 6	VETTA II HEAD	Amp Head	G-901	G-TOUR-AMP HEAD			
MACKIE	808	Powered Mixer	GMC-2222				
MACKIE	1202 VLZ PRO	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17	GMC-2222	
MACKIE	1202-VLZ3	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17	GMC-2222	
MACKIE	1402 VLZ PRO	Mixer	G-MIX-B 1515	G-MIX-L 1618	G-MIX 17 x 18	GMC-2222	
MACKIE	1402-VLZ3	Mixer	G-MIX-B 1515	G-MIX-L 1618	G-MIX 17 x 18	GMC-2222	
MACKIE	1604 VLZ PRO	Mixer	G-MIX-B 1818	G-MIX-L 1822	G-MIX 19X21	G-TOUR 19X21	GMC-2222
MACKIE	1642 VLZ PRO	Mixer	G-MIX-B 1818	G-MIX-L 1822	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
MACKIE	1642-VLZ3	Mixer	G-MIX-B 1818	G-MIX-L 1822	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
MACKIE	24E	Mixer	GMC-3333				
MACKIE	24X4	Mixer	G-MIX 24 x 36	G-TOUR 24 x 36	GMC-3333	GMC-4221	
MACKIE	406M	Powered Mixer	GMC-2222				
MACKIE	808M	Powered Mixer	GMC-2222				
MACKIE	808S	Powered Mixer	GMC-2222				
MACKIE	C200	Speaker	GPA-600				
MACKIE	C300Z	Speaker	GPA-777				
MACKIE	CFX 12	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
MACKIE	CFX 16	Mixer	G-MIX-L 1622	G-MIX-L 1822	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222
MACKIE	CFX 20	Mixer	G-MIX 20 x 30	G-TOUR 20 x 30	GMC-3333	GMC-4221	
MACKIE	CFX12MK2	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
MACKIE	CFX16MK2	Mixer	G-MIX-L 1622	G-MIX-L 1822	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222
MACKIE	CFX20MK2	Mixer	G-MIX 20 x 30	G-TOUR 20 x 30	GMC-3333	GMC-4221	
MACKIE	D2	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222			
MACKIE	DFX 12	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
MACKIE	DFX 6	Mixer	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	
MACKIE	HR624	Studio Monitor	GPA-600	GMC-2222			
MACKIE	HUI	Mixer	G-MIX-B 1818	G-MIX-L 1822	G-MIX 19X21	G-TOUR 19X21	GMC-2222
MACKIE	MS1402-VLZ	Mixer	G-MIX-B 1515	G-MIX-L 1618	G-MIX 17 x 18	GMC-2222	
MACKIE	ONYX 1220	Mixer	G-MIX-L 1618	G-MIX 17 x 18	G-MIX 19X21	G-TOUR 19X21	GMC-2222
MACKIE	ONYX 1620	Mixer	G-MIX-L 1822	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222
MACKIE	ONYX 1640	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-3333	GMC-4221	
MACKIE	ONYX 24-4	Mixer	GMC-3333				
MACKIE	SR24.4 VLZ PRO	Mixer	G-MIX 24 x 36	G-TOUR 24 x 36	GMC-3333	GMC-4221	
MACKIE	SR32.4 VLZ PRO	Mixer	G-MIX 22 x 46	GMC-4221			
MACKIE	SRM350	Speaker	GPA-600				
MACKIE	SRM450	Speaker	GPA-777				
MACKIE	SWA1501	Speaker - Sub	G-Sub-2225-24 Bag				
MACKIE	TAPCO 6306	Mixer	G-MIX-B 1212				
MARANTZ	PD4293D	LCD/Plasma	G-TourLCDP3743				
MARANTZ	PD5010D	LCD/Plasma	G-TourLCDP50				
MARSHALL	1912	Combo Amp 1x15	G-112A				
MARSHALL	1922	Combo Amp 2x12	G-212A	G-TOUR 2430			
MARSHALL	1936	Guitar Speaker Cab	G-TOUR 2430				
MARSHALL	2203	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	2245	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	2266	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	2466	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	4100	Amp Head	G-TOUR-AMP HEAD				
MARSHALL	1959SLPX	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	1962BLUESBREAKER	Combo Amp 2x12	G-TOUR 2430				
MARSHALL	1974CX	Combo Amp 1x12	G-112A	G-212A			
MARSHALL	1982 AJH	Guitar Speaker Cab	G-Tour 4x12				
MARSHALL	1987X	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	2266C	Combo Amp 2x12	G-212A	G-TOUR 2430			
MARSHALL	425A	Guitar Speaker Cab	G-Tour 4x12				
MARSHALL	425B	Guitar Speaker Cab	G-Tour 4x12				
MARSHALL	AS50D	Combo Amp	G-112A	G-TOUR 2226			
MARSHALL	AVT100X	Combo Amp 1x12	G-TOUR 2226				
MARSHALL	AVT112X	Guitar Speaker Cab	G-TOUR 2226				
MARSHALL	AVT150	Combo Amp 2x12	G-112A	G-TOUR 2226			
MARSHALL	AVT150H	Amp Head	G-901	G-TOUR-AMP HEAD			

Gator Cases Master Cross Reference

Updated 9/19/07

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
MARSHALL	AVT150HX	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	AVT150X	Combo Amp 1x12	G-TOUR 2226				
MARSHALL	AVT20X	Combo Amp	G-112A				
MARSHALL	AVT275X	Combo Amp 2x12	G-212A	G-TOUR 2430			
MARSHALL	AVT412A	Guitar Speaker Cab	G-Tour 4x12				
MARSHALL	AVT412B	Guitar Speaker Cab	G-Tour 4x12				
MARSHALL	AVT412XA	Guitar Speaker Cab	G-Tour 4x12				
MARSHALL	AVT412XB	Guitar Speaker Cab	G-Tour 4x12				
MARSHALL	AVT50H	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	AVT50HX	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	AVT50X	Combo Amp 1x12	G-112A	G-TOUR 2226			
MARSHALL	B65	Combo Amp 1x12	G-112A	G-TOUR 2226			
MARSHALL	DSL100	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	DSL401	Combo Amp 1x12	G-112A	G-TOUR 2226			
MARSHALL	DSL50	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	JCM800 2203X	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	JCM900	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	JTM100	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	JTM45	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	JVM410C	Combo Amp 4x10	G-212A	G-TOUR 2430			
MARSHALL	JVM410H	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	LEAD 100 MOSFET	Amp Head	G-901				
MARSHALL	MB4210	Combo Amp 2x10	G-112A	G-212A	G-TOUR 2226	G-TOUR 2430	
MARSHALL	MB60	Combo Amp 1x12	G-TOUR 2226				
MARSHALL	MF350	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	MG100DFX	Combo Amp 1x12	G-TOUR 2226				
MARSHALL	MG250DFX	Combo Amp 2x12	G-212A	G-TOUR 2430			
MARSHALL	MG412	Guitar Speaker Cab	G-Tour 4x12				
MARSHALL	MG50DFX	Combo Amp 1x12	G-112A	G-TOUR 2226			
MARSHALL	SUPER100JH	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	TSL100	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	TSL122	Combo Amp 2x12	G-212A	G-TOUR 2430			
MARSHALL	TSL60	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	TSL601	Combo Amp 1x12	G-112A	G-TOUR 2226			
MARSHALL	TSL602	Combo Amp 2x12	G-212A	G-TOUR 2430			
MARSHALL	VBA400	Amp Head	G-TOUR-AMP HEAD				
MARSHALL	VM2266C	Combo Amp 2x12	G-TOUR 2430				
MARSHALL	VM2266H	Amp Head	G-901	G-TOUR-AMP HEAD			
MARSHALL	VM2466H	Amp Head	G-901	G-TOUR-AMP HEAD			
M-AUDIO	2	Keyboard	GK-2110	GK-LT25W			
M-AUDIO	AXIOM 25 KEY	Keyboard	GK-2110	GK-LT25W			
M-AUDIO	AXIOM 49 KEY	Keyboard	GKB-49	GK-49			
M-AUDIO	AXIOM 61	Keyboard	GK-4212				
M-AUDIO	BX10SUB	Studio Monitor	GMC-2222				
M-AUDIO	FIREWIRE SOLO	Digital Interface	G-TOUR 12X17				
M-AUDIO	KEYSTATION 61ES	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
M-AUDIO	KEYSTATION 88 ES	Keyboard	GKB-88 Slim	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim	
M-AUDIO	KEYSTATION PRO88	Keyboard	GKC-1648				
M-AUDIO	MIDAIR 25 KEY	Keyboard	GK-2110	GK-LT25W			
M-AUDIO	MIDAIR 37	Keyboard	GK-2110	GK-LT25W			
M-AUDIO	O2 25 KEY	Keyboard	GK-2110	GK-LT25W			
M-AUDIO	OXYGEN 49	Keyboard	GKB-49	GK-49			
M-AUDIO	OXYGEN 61	Keyboard	GKB-49	GK-49	GK-4212		
M-AUDIO	OXYGEN8	Keyboard	GK-2110	GK-LT25W			
M-AUDIO	OZONE	Keyboard	GK-2110	GK-LT25W			
M-AUDIO	PROJECT MIN I/O	Recording Workstation	GMC-3333				
M-AUDIO	PROJECT MIX I/O	Recording Interface	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	G-TOUR 20 x 25	GMC-2222
M-AUDIO	PROKEYS 88	Keyboard	GKC-1648				
M-AUDIO	PROKEYS 88SX	Keyboard	GKB-88 Slim	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim	
M-AUDIO	RADIUM61	Keyboard	GK-4212				
M-AUDIO	TRIGGERFINGER	Recording Interface	G-MIX-B 1212	G-TOUR 12X17	GMC-2222		
MESABOOGIE	112 LONESTAR 23	Guitar Speaker Cab	G-112A	G-TOUR 2226			
MESABOOGIE	112 LONESTAR 27	Guitar Speaker Cab	G-212A	G-TOUR 2430			
MESABOOGIE	112 THREE-QUARTER BACK	Guitar Speaker Cab	G-212A	G-TOUR 2430			
MESABOOGIE	112 WIDE BODY	Guitar Speaker Cab	G-112A	G-TOUR 2226			
MESABOOGIE	212 LONESTAR	Guitar Speaker Cab	G-212A	G-TOUR 2430			
MESABOOGIE	410 LONESTAR	Guitar Speaker Cab	G-Tour 4x12				
MESABOOGIE	412 LONESTAR	Guitar Speaker Cab	G-Tour 4x12				
MESABOOGIE	412 STILETTO	Guitar Speaker Cab	G-Tour 4x12				
MESABOOGIE	NOMAD 45 112	Combo Amp 1x12	G-112A				
MEYER SOUND	M1D SUB	Speaker - Sub	GPA-700	GPA-777			
MEYER SOUND	UMS-1P	Speaker - Sub	GPA-700				
MICROBOARDS	COPYWRITER 1052	Media Player	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-3333	GMC-4221	
MICROBOARDS	DVD RPM 1016	Media Player	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-3333	GMC-4221	
MICROBOARDS	GX1	Media Player	GMC-3333	GMC-4221			
MICROTEK	CX4	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO		
MICROTEK	MHP1	LCD/Plasma	G-TourLCDP50				
MICROTEK	VS1	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
MIDAS	VENICE-1608	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-3333		
MIDAS	VENICE-24016	Mixer	GMC-3333				
MISUBISHI	XD450U	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
MITSUBISHI	PD-5010	LCD/Plasma	G-TourLCDP50				
MITSUBISHI	XD430U	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
MITSUBISHI	XL8U	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
MOTU	TRAVELER	Digital Interface	G-TOUR 12X17				
MUSICXPC	M4	Laptop	GK-LT25W	G-TourCarryOnPL	GRC-STUDIO-2-GC	GRC-STUDIO-4-GC	GAV-1813R
MUSICXPC	M4X	Laptop	GK-LT25W	G-TourCarryOnPL	GRC-STUDIO-2-GC	GRC-STUDIO-4-GC	GAV-1813R

Gator Cases Master Cross Reference
 Updated 9/19/07

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
NADY	6600	Powered Mixer	GPA-720	GMC-2222			
NADY	CMX16A	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
NADY	MC12	Speaker	GPA-700	GPA-600	GPA-777		
NADY	MC15	Speaker	GPA-700	GPA-777			
NADY	MM4	Mixer	G-MIX-B 1212				
NADY	MPM4130	Mixer	GMC-2222				
NADY	MPM8175	Powered Mixer	GPA-720	GMC-2222			
NADY	MXE1212	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
NADY	PFW12	Speaker	GPA-700				
NADY	PRM400	Mixer	G-MIX-B 2020	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
NADY	PS112	Speaker	GPA-700	GPA-600			
NADY	PSW15	Speaker - Sub	GPA-700				
NADY	PSW18	Speaker - Sub	G-Sub-2225-24 Bag				
NADY	PTS 1015	Speaker	GPA-700	GPA-777			
NADY	PTS515	Speaker	GPA-700	GPA-777			
NADY	RPA2	Speaker	GPA-600				
NADY	SPM6600	Powered Mixer	GPA-720	GMC-2222			
NADY	SPM8600	Powered Mixer	GPA-720	GMC-2222			
NADY	SRM10X	Mixer	G-MIX-B 1212				
NADY	SRM12X	Mixer	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	
NADY	SRM-14X	Mixer	G-MIX-B 1515	G-MIX 17 x 18	GMC-2222		
NEC	3300	LCD/Plasma	G-TourLCDP2632				
NEC	4000	LCD/Plasma	G-TourLCDP3743				
NEC	5000	LCD/Plasma	G-TourLCDP50				
NEC	1740CX	LCD/Plasma	G-MIX-L 1618	GAV-1813R			
NEC	1770VX	LCD/Plasma	G-MIX-L 1618	GAV-1813R			
NEC	1940CX	LCD/Plasma	G-MIX-L 1618	G-MIX-L 1622			
NEC	1990SX1	LCD/Plasma	G-MIX-L 1618	GAV-1813R			
NEC	2090UXI	LCD/Plasma	G-MIX-L 1618	G-MIX-L 1622	G-TourLCDP2023		
NEC	20WVGX2	LCD/Plasma	G-MIX-L 1622				
NEC	42PD1	LCD/Plasma	G-TourLCDP3743				
NEC	42PD2	LCD/Plasma	G-TourLCDP3743				
NEC	42VM5	LCD/Plasma	G-TourLCDP3743				
NEC	42VP4	LCD/Plasma	G-TourLCDP3743				
NEC	42VP5	LCD/Plasma	G-TourLCDP3743				
NEC	42VP5A	LCD/Plasma	G-TourLCDP3743				
NEC	42XM3	LCD/Plasma	G-TourLCDP3743				
NEC	42XM3A	LCD/Plasma	G-TourLCDP3743				
NEC	50MP1	LCD/Plasma	G-TourLCDP50				
NEC	50MP2	LCD/Plasma	G-TourLCDP50				
NEC	50MP3	LCD/Plasma	G-TourLCDP50				
NEC	50PD1	LCD/Plasma	G-TourLCDP50				
NEC	50XM3	LCD/Plasma	G-TourLCDP50				
NEC	50XM4A	LCD/Plasma	G-TourLCDP50				
NEC	50XM5	LCD/Plasma	G-TourLCDP50				
NEC	50XR4A	LCD/Plasma	G-TourLCDP50				
NEC	61 XMA	LCD/Plasma	G-TourLCDP60				
NEC	61 XR4	LCD/Plasma	G-TourLCDP60				
NEC	70GX2	LCD/Plasma	G-MIX-L 1618	GAV-1813R			
NEC	90GX2	LCD/Plasma	G-MIX-L 1618	G-MIX-L 1622			
NEC	ACCUSYNC 92VX	LCD/Plasma	G-MIX-L 1618	G-MIX-L 1622	G-MIX-L 1822		
NEC	LCD1570NX	LCD/Plasma	GAV-1412R	GAV-1813R	GAV-20		
NEC	LCD1770GX	LCD/Plasma	G-MIX-L 1618	GAV-1813R			
NEC	LCD1770NX	LCD/Plasma	G-MIX-L 1618	GAV-1813R			
NEC	LCD1770NXM	LCD/Plasma	G-MIX-L 1618				
NEC	LCD17V	LCD/Plasma	G-MIX-L 1618	GAV-1813R			
NEC	LCD1970	LCD/Plasma	G-MIX-L 1618	G-MIX-L 1622			
NEC	LCD1970V	LCD/Plasma	G-MIX-L 1618	G-MIX-L 1622			
NEC	LCD2070NX	LCD/Plasma	G-MIX-L 1618	G-MIX-L 1622			
NEC	LCD2170NX	LCD/Plasma	G-MIX-L 1622	G-MIX-L 1822	G-TourLCDP2023		
NEC	LCD2180WGLED	LCD/Plasma	G-MIX-L 1622	G-MIX-L 1822	G-TourLCDP2023		
NEC	LCD2190UXI	LCD/Plasma	G-MIX-L 1622	G-MIX-L 1822	G-TourLCDP2023		
NEC	LCD2335 WXM	LCD/Plasma	G-TourLCDP2023				
NEC	LCD3210	LCD/Plasma	G-TourLCDP2632				
NEC	LCD4010	LCD/Plasma	G-TourLCDP3743				
NEC	LCD52V	LCD/Plasma	GAV-1412R	GAV-1813R			
NEC	LCD52VM	LCD/Plasma	GAV-1412R	GAV-1813R			
NEC	LCD72VX	LCD/Plasma	G-MIX-L 1618	GAV-1813R			
NEC	LCD92VX	LCD/Plasma	G-MIX-L 1618	G-MIX-L 1622	G-MIX-L 1822		
NEC	LT265	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO		
NEC	MT1055	Projector	G-TourCarryOnFO				
NEC	PX-42V5RA	LCD/Plasma	G-TourLCDP3743				
NEC	PX-42VMA	LCD/Plasma	G-TourLCDP3743				
NEC	PX-42VP4A	LCD/Plasma	G-TourLCDP3743				
NEC	PX-42XM2A	LCD/Plasma	G-TourLCDP3743				
NEC	VT-37	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
NEC	VT-47	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
NEC	VT-470	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
NEC	VT-570	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
NEC	VT-575	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
NEC	VT-670	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
NEC	VT-676	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
NEC	VT-770	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO		
NORD	ELECTRO 2 61	Keyboard	GKB-49	GK-49	GK-4212	GKC-1540	
NORD	ELECTRO 2 73	Keyboard	GK-261R	G-Tour 61	GKC-1540		
NORD	STAGE88	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	
NOVATION	REMOTE25 SL	Keyboard	GK-2110	GK-LT25W			

Gator Cases Master Cross Reference

Updated 9/19/07

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
NOVATION	REMOTE-25LE	Keyboard	GK-LT25W				
NOVATION	REMOTE49	Keyboard	GKB-49	GK-49			
NOVATION	REMOTE61	Keyboard	GK-4212				
NOVATION	XIO-SYNTH25	Keyboard	GK-2110	GK-LT25W			
NOVATION	XSTATION 25	Keyboard	GK-2110	GK-LT25W			
NOVATION	XSTATION 49	Keyboard	GKB-49	GK-49			
NOVATION	XSTATION 61	Keyboard	GK-4212				
NUMARK	5000FX	Pro DJ - Mixer	G-MIX-B 1515	G-MIX-L 1618	G-MIX 17 x 18	GMC-2222	G-Tour-CDMX13x17
NUMARK	AXIS 2	Pro DJ - CD Player	GDJ-DJ Case				
NUMARK	AXIS 4	Pro DJ - CD Player	GDJ-DJ Case				
NUMARK	AXIS 8	Pro DJ - CD Player	G-Tour-CD-9x12	G-Tour-CDMX9x12			
NUMARK	AXIS 9	Pro DJ - CD Player	G-Tour-CD-9x12	G-Tour-CDMX9x12			
NUMARK	CD2CD	Pro DJ - CD Player	G-Tour-CD-9x12	G-Tour-CDMX9x12	GDJ-i-GO		
NUMARK	CDX	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
NUMARK	DM1001X	Pro DJ - Mixer	G-MIX-B 1212				
NUMARK	DM1002 MKII	Pro DJ - Mixer	G-MIX-B 1212	G-TOUR 12X17	G-Tour-CDMX9x12		
NUMARK	DM1050	Pro DJ - Mixer	G-MIX-B 1212	G-TOUR 12X17	G-Tour-CDMX9x12	GDJ-i-GO	
NUMARK	DM2050	Pro DJ - Mixer	G-MIX-B 1212	G-TOUR 12X17	G-Tour-CDMX9x12		
NUMARK	DM3001X	Pro DJ - Mixer	G-TOUR 12X17				
NUMARK	DM3002X	Pro DJ - Mixer	G-TOUR 12X17				
NUMARK	DM3050	Pro DJ - Mixer	G-Tour-CD-13x17	G-Tour-CDMX13x17	G-TOUR 12X17		
NUMARK	DM950	Pro DJ - Mixer	G-Tour-CD-9x12	G-Tour-CDMX9x12	G-MIX-B 1212		
NUMARK	DM950 USB	Pro DJ - Mixer	G-Tour-CD-9x12	G-Tour-CDMX9x12	G-MIX-B 1212		
NUMARK	DMX01	Pro DJ - Mixer	G-Tour-CDMX9x12	G-MIX-B 1212	G-TOUR 12X17		
NUMARK	DMX03	Pro DJ - Mixer	G-Tour-CD-13x17	G-Tour-CDMX13x17	G-TOUR 12X17		
NUMARK	DMX06	Pro DJ - Mixer	G-Tour-CD-13x17	G-Tour-CDMX13x17	G-TOUR 12X17		
NUMARK	DXM01 USB	Pro DJ - Mixer	G-Tour-CD-13x17	G-Tour-CDMX13x17	G-TOUR 12X17		
NUMARK	DXM06	Pro DJ - Mixer	G-Tour-CD-13x17	G-Tour-CDMX13x17	G-TOUR 12X17		
NUMARK	DXM09	Pro DJ - Mixer	G-Tour-CD-13x17	G-Tour-CDMX13x17	G-TOUR 12X17	GMC-2222	
NUMARK	DXMPRO	Pro DJ - Mixer	G-MIX 19X21	G-TOUR 19X21	GMC-2222		
NUMARK	HDX	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
NUMARK	ICDX	Pro DJ - CD Player	G-Tour-CDMX9x12				
NUMARK	IDJ	Pro DJ - Mixer	G-MIX-B 1212	G-TOUR 12X17	GMC-2222	G-Tour-CDMX9x12	GDJ-i-GO
NUMARK	IDJ2	Pro DJ - Mixer	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	G-Tour-CDMX13x17	GMC-2222
NUMARK	MATRIX 2	Pro DJ - Mixer	GDJ-DJ Case	G-TOUR 12X17			
NUMARK	MATRIX 3	Pro DJ - Mixer	GDJ-DJ Case	G-TOUR 12X17			
NUMARK	NUVJ	Pro DJ - Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222	GMC-3333	
NUMARK	PPD01	Pro DJ - Mixer	G-Tour-CD-13x17	G-Tour-CDMX13x17	G-TOUR 12X17	GMC-2222	
NUMARK	PT01	Pro DJ - Turntable	G-Tour-CDMX9x12				
NUMARK	TT1600MKII	Pro DJ - Turntable	GDJ-1500	G-Tour-T-Table			
NUMARK	TT1650	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
NUMARK	TT200	Pro DJ - Turntable	GDJ-1500				
NUMARK	TT500	Pro DJ - Turntable	GDJ-1500	G-Tour-T-Table			
NUMARK	TTUSB	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
NUMARK	TTX	Pro DJ - Turntable	GDJ-1500	G-Tour-T-Table			
NUMARK	VJ01	Pro DJ - CD Player	GDJ-DJ Case				
OPEN LABS	NEKO 64 61	Keyboard	GKC-1648				
OPEN LABS	NEKO 64 76	Keyboard	GKC-1648				
OPEN LABS	NEKO LE 61	Keyboard	GKC-1648				
OPEN LABS	NEKO LE 76	Keyboard	GKC-1648				
OPTOMA	EZ PRO 716	Projector	GAV-1412R				
OPTOMA	EZ PRO 719	Projector	GAV-1412R				
OPTOMA	EZ PRO 732	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
OPTOMA	EZ PRO 738	Projector	GAV-20	GAV-DLX-20			
OPTOMA	EZ PRO 739	Projector	GAV-20	GAV-DLX-20			
OPTOMA	EZ PRO 741	Projector	GAV-20	GAV-DLX-20			
OPTOMA	EZ PRO 745	Projector	GAV-20	GAV-DLX-20			
OPTOMA	EZ PRO 747	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
OPTOMA	EZ PRO 751	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO		
OPTOMA	EZ PRO 758	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO		
OPTOMA	EZ PRO 759	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnFO		
PANASONIC	PT-37PD1	LCD/Plasma	G-TourLCDP3743				
PANASONIC	PT-37PD1P	LCD/Plasma	G-TourLCDP3743				
PANASONIC	PT-42P1	LCD/Plasma	G-TourLCDP3743				
PANASONIC	PT-50PD3-P	LCD/Plasma	G-TourLCDP50				
PANASONIC	PT-AE700U	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	G-TourCarryOnFO	G-TourCarryOnPL
PANASONIC	PT-L500U	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
PANASONIC	PT-L785U	Projector	G-TourCarryOnFO				
PANASONIC	PTLB10SVU	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
PANASONIC	PT-LB10U	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
PANASONIC	PTLB10VU	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
PANASONIC	PT-LB20NTU	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
PANASONIC	PTLB20SU	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
PANASONIC	PTLB20U	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
PANASONIC	PTLB20VU	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
PANASONIC	PT-LB30	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
PANASONIC	PTLB30NTU	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
PANASONIC	PTLB50NTU	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
PANASONIC	PTLB50SU	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
PANASONIC	PTLB50U	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
PANASONIC	PTLB60NTU	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
PANASONIC	PTLB60U	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
PANASONIC	PT-LM1	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
PANASONIC	PT-LM2	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
PANASONIC	TC23LX50	LCD/Plasma	G-TourLCDP2023				
PANASONIC	TC-32LX60	LCD/Plasma	G-TourLCDP2632				
PANASONIC	TC-37P1F	LCD/Plasma	G-TourLCDP3743				

Gator Cases Master Cross Reference

Updated 9/19/07

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
PANASONIC	TH37PH9UK	LCD/Plasma	G-TourLCDP3743				
PANASONIC	TH-37PWD5UX	LCD/Plasma	G-TourLCDP3743				
PANASONIC	TH-37PWD6	LCD/Plasma	G-TourLCDP3743				
PANASONIC	TH-37PWD7UY	LCD/Plasma	G-TourLCDP3743				
PANASONIC	TH-42PDD3B	LCD/Plasma	G-TourLCDP3743				
PANASONIC	TH-42PH9UK	LCD/Plasma	G-TourLCDP3743				
PANASONIC	TH-42PHD5UY	LCD/Plasma	G-TourLCDP3743				
PANASONIC	TH-42PHD6	LCD/Plasma	G-TourLCDP3743				
PANASONIC	TH-42PHD6UY	LCD/Plasma	G-TourLCDP3743				
PANASONIC	TH-42PHD7UY	LCD/Plasma	G-TourLCDP3743				
PANASONIC	TH-42PHD8UK	LCD/Plasma	G-TourLCDP3743				
PANASONIC	TH42PS9UK	LCD/Plasma	G-TourLCDP3743				
PANASONIC	TH-42PWD3U	LCD/Plasma	G-TourLCDP3743				
PANASONIC	TH-42PWD5UY	LCD/Plasma	G-TourLCDP3743				
PANASONIC	TH-42PWD6UY	LCD/Plasma	G-TourLCDP3743				
PANASONIC	TH50PF9UK	LCD/Plasma	G-TourLCDP50				
PANASONIC	TH-50PH9	LCD/Plasma	G-TourLCDP50				
PANASONIC	TH-50PH9UK	LCD/Plasma	G-TourLCDP50				
PANASONIC	TH-50PHD3U	LCD/Plasma	G-TourLCDP50				
PANASONIC	TH-50PHD5UY	LCD/Plasma	G-TourLCDP50				
PANASONIC	TH-50PHD7UY	LCD/Plasma	G-TourLCDP50				
PANASONIC	TH-50PX	LCD/Plasma	G-TourLCDP50				
PANASONIC	TH-50PX6	LCD/Plasma	G-TourLCDP50				
PANASONIC	TH-50THD6UI	LCD/Plasma	G-TourLCDP50				
PANASONIC	TH-50THD6UY	LCD/Plasma	G-TourLCDP50				
PANASONIC	TH58PX6	LCD/Plasma	G-TourLCDP60				
PEAVEY	16FX	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222		
PEAVEY	24FX	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-3333	GMC-4221	
PEAVEY	32FX	Mixer	GMC-3333	GMC-4221			
PEAVEY	6505 HEAD	Amp Head	G-901	G-TOUR-AMP HEAD			
PEAVEY	6505 PLUS HEAD	Amp Head	G-901	G-TOUR-AMP HEAD			
PEAVEY	BANDIT 112	Combo Amp 1x12	G-112A	G-TOUR 2226			
PEAVEY	CLASSIC 212	Combo Amp 2x12	G-Tour 4x12				
PEAVEY	CLASSIC 30	Combo Amp 1x12	G-112A	G-TOUR 2226			
PEAVEY	CLASSIC 50/212	Combo Amp 2x12	G-212A	G-TOUR 2430			
PEAVEY	CLASSIC 50/410	Combo Amp 4x10	G-TOUR 2430				
PEAVEY	DELTA BLUES 115	Combo Amp 1x15	G-112A	G-TOUR 2226			
PEAVEY	DELTA BLUES 210	Combo Amp 1x12	G-TOUR 2226				
PEAVEY	JSX 212COMBO	Combo Amp 2x12	G-212A	G-TOUR 2430			
PEAVEY	JSX HEAD	Amp Head	G-TOUR-AMP HEAD				
PEAVEY	JSX412	Guitar Speaker Cab	G-Tour 4x12				
PEAVEY	MAX 115	Combo Amp	G-TOUR 2226	G-TOUR 2430			
PEAVEY	MP600	Powered Mixer	GMC-2222				
PEAVEY	NASHVILLE 1000	Combo Amp 1x15	G-212A	G-TOUR 2430			
PEAVEY	NASHVILLE 112	Combo Amp 1x12	G-112A	G-TOUR 2226			
PEAVEY	PENTA 412	Guitar Speaker Cab	G-Tour 4x12				
PEAVEY	PENTA HEAD	Amp Head	G-TOUR-AMP HEAD				
PEAVEY	PR 10 NEO	Speaker	GPA-600				
PEAVEY	PR 12 NEO	Speaker	GPA-700	GPA-777			
PEAVEY	PR 15 NEO	Speaker	G-Sub-2225-24 Bag				
PEAVEY	PR SUB 15	Speaker - Sub	G-Sub-2225-24 Bag				
PEAVEY	PV 118	Speaker - Sub	G-Sub-2225-24 Bag				
PEAVEY	PV 12M	Speaker	GPA-700				
PEAVEY	PV 15M	Speaker	GPA-700	GPA-777			
PEAVEY	PV10	Mixer	G-MIX-B 1515	G-MIX-L 1618	G-MIX 17 x 18	GMC-2222	
PEAVEY	PV14	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
PEAVEY	PV8	Mixer	G-MIX-B 1212	G-TOUR 12X17			
PEAVEY	RQ 1606M	Mixer	G-MIX 20 x 30	G-TOUR 20 x 30	GMC-3333	GMC-4221	
PEAVEY	RQ 200	Mixer	G-TOUR 12X17	GMC-2222			
PEAVEY	RQ 2310	Mixer	G-MIX-B 2020	G-MIX-L 1822	G-MIX 19X21	G-TOUR 19X21	GMC-2222
PEAVEY	RQ 2314	Mixer	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	G-TOUR 20 x 25	GMC-2222
PEAVEY	RQ 2318	Mixer	G-MIX 20 x 25	G-MIX 20 x 30	G-TOUR 20 x 25	G-TOUR 20 x 30	GMC-3333
PEAVEY	RQ 2326	Mixer	GMC-3333	GMC-4221			
PEAVEY	RQ 4324C	Mixer	GMC-4221				
PEAVEY	STUDIO PRO 112	Combo Amp 1x12	G-112A	G-TOUR 2226			
PEAVEY	SUPREME XL HEAD	Amp Head	G-TOUR-AMP HEAD				
PEAVEY	TRANSTUBE 112 EFX	Combo Amp 1x12	G-112A	G-TOUR 2226			
PEAVEY	TRIPLE XXX	Guitar Speaker Cab	G-212A	G-TOUR 2430			
PEAVEY	TRIPLE XXX 112	Combo Amp 1x12	G-112A	G-TOUR 2226			
PEAVEY	TRIPLE XXX 212	Combo Amp 2x12	G-212A	G-TOUR 2430			
PEAVEY	TRIPLE XXX 412	Guitar Speaker Cab	G-Tour 4x12				
PEAVEY	TRIPLE XXX HEAD	Amp Head	G-TOUR-AMP HEAD				
PEAVEY	UNITY 1002-8 RQ	Mixer	G-MIX-B 1818	G-MIX-L 1822	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
PEAVEY	VALVE KING 412	Guitar Speaker Cab	G-Tour 4x12				
PEAVEY	VALVEKING 100 HEAD	Amp Head	G-901	G-TOUR-AMP HEAD			
PEAVEY	VALVEKING 112	Combo Amp 1x12	G-112A	G-TOUR 2226			
PEAVEY	VALVEKING 212	Combo Amp 2x12	G-212A	G-TOUR 2430			
PEAVEY	VALVEKING FOOTSWITCH	Guitar Multi-Effects	G-MIX-B 1212				
PEAVEY	WIGGY 212	Combo Amp 2x12	G-Tour 4x12				
PEAVEY	WINDSOR 412	Guitar Speaker Cab	G-Tour 4x12				
PEAVEY	WINDSOR HD	Amp Head	G-TOUR-AMP HEAD				
PEAVEY	XR 1600F	Mixer	GMC-3333	GMC-4221			
PEAVEY	XR 560	Powered Mixer	GMC-2222				
PEAVEY	XR 684F	Powered Mixer	GPA-720	GMC-2222			
PEAVEY	XR 800F	Mixer	GMC-2222				
PEAVEY	XR 800F PLUS	Mixer	G-MIX-L 1822	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222
PEAVEY	XR 8300	Powered Mixer	GMC-2222	GMC-3333			

Gator Cases Master Cross Reference
Updated 9/19/07

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
PEAVEY	XR 8600	Powered Mixer	GMC-2222	GMC-3333			
PEAVEY	XR600G	Powered Mixer	GPA-720	GMC-2222			
PEAVEY	XR696F	Powered Mixer	GPA-720	GMC-2222			
PEAVEY	XXL	Combo Amp 2x12	G-212A	G-TOUR 2430			
PEAVEY	XXL	Guitar Speaker Cab	G-212A	G-TOUR 2430			
PEAVEY	XXL HEAD	Amp Head	G-TOUR-AMP HEAD				
PHILIPS	20PF5120	LCD/Plasma	G-MIX-L 1822				
PHILIPS	20PF5120	LCD/Plasma	G-TourLCDP2023				
PHILIPS	42FD9954	LCD/Plasma	G-TourLCDP50				
PHILIPS	42FD9955	LCD/Plasma	G-TourLCDP50				
PHILIPS	42PW9962	LCD/Plasma	G-TourLCDP50				
PHILIPS	42PW9982	LCD/Plasma	G-TourLCDP50				
PHILIPS	50FD9955	LCD/Plasma	G-TourLCDP50				
PHILIPS	50PF7321	LCD/Plasma	G-TourLCDP60				
PHILIPS	50PF9630A	LCD/Plasma	G-TourLCDP60				
PHILIPS	50PF9830	LCD/Plasma	G-TourLCDP60				
PHONIC	HELIX 18FW	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
PHONIC	HELIX BOARD 12	Mixer	G-MIX-B 1212				
PHONIC	HELIX BOARD 17	Mixer	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	
PHONIC	MM1202	Mixer	G-MIX-B 1212				
PHONIC	MM1705	Mixer	G-MIX-B 1515	G-MIX 17 x 18	GMC-2222		
PHONIC	MM1805(X)	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
PHONIC	MR 1843X	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
PHONIC	MR3243	Mixer	G-MIX 24 x 36	G-TOUR 24 x 36			
PHONIC	MR4243(D)	Mixer	G-MIX 22 x 46				
PHONIC	MR4283	Mixer	G-MIX 22 x 46				
PHONIC	MR4283D	Mixer	G-MIX 22 x 46				
PHONIC	MRS 1-20	Mixer	G-MIX 24 x 36	G-TOUR 24 x 36			
PHONIC	MRS 1-30	Mixer	G-MIX 22 x 46				
PHONIC	MU1202	Mixer	G-MIX-B 1212				
PHONIC	PAA3	Media Player	GMC-2222				
PHONIC	POWERPOD 1840	Mixer	G-MIX-B 2020	G-MIX 19X21	G-TOUR 19X21	GMC-2222	
PHONIC	POWERPOD 1860II	Mixer	G-MIX-B 2020	G-MIX 19X21	G-TOUR 19X21	GMC-2222	
PHONIC	POWERPOD 2280	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222	GMC-3333	
PHONIC	POWERPOD 620	Powered Mixer	GPA-720	GMC-2222			
PHONIC	POWERPOD 740	Powered Mixer	GPA-720	GMC-2222			
PIONEER	614MX	LCD/Plasma	G-TourLCDP60				
PIONEER	CDJ-1000 MK3	Pro DJ - CD Player	G-Tour-CD-13x17	G-Tour-CDMX13x17	G-Tour-T-Table		
PIONEER	CDJ-1000 MKII	Pro DJ - CD Player	G-Tour-CD-13x17	G-Tour-CDMX13x17	G-Tour-T-Table		
PIONEER	CDJ-100S	Pro DJ - CD Player	G-Tour-CD-9x12	G-Tour-CDMX9x12	GDJ-DJ Case		
PIONEER	CDJ-200	Pro DJ - CD Player	G-Tour-CD-9x12	G-Tour-CDMX9x12	GDJ-DJ Case		
PIONEER	DJC3000RV	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
PIONEER	DJM-1000	Pro DJ - Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222		
PIONEER	DJM-300	Pro DJ - Mixer	G-TOUR 12X17				
PIONEER	DJM-3000	Pro DJ - Mixer	G-MIX-L 1224				
PIONEER	DJM-300S	Pro DJ - Mixer	G-TOUR 12X17				
PIONEER	DJM-400	Pro DJ - Mixer	G-Tour-CD-9x12	G-Tour-CDMX9x12	GDJ-DJ Case	G-MIX-B 1212	G-TOUR 12X17
PIONEER	DJM-500	Pro DJ - Mixer	G-MIX-B 1515	G-MIX-L 1618	G-MIX 17 x 18	GMC-2222	G-Tour-T-Table
PIONEER	DJM-600	Pro DJ - Mixer	G-MIX-B 1515	G-MIX-L 1618	G-MIX 17 x 18	GMC-2222	G-Tour-T-Table
PIONEER	DJM-707	Pro DJ - Mixer	G-Tour-CD-13x17	G-Tour-CDMX13x17	G-TOUR 12X17		
PIONEER	DJM-800	Pro DJ - Mixer	G-MIX-B 1515	G-MIX-L 1618	G-MIX 17 x 18	GMC-2222	G-Tour-CD-13x17
PIONEER	DJM-909	Pro DJ - Mixer	G-Tour-CD-13x17	G-Tour-CDMX13x17	G-TOUR 12X17		
PIONEER	DMP-555	Pro DJ - CD Player	G-Tour-CD-13x17	G-Tour-CDMX13x17			
PIONEER	DVD-V7300D	Mixer	G-TOUR 12X17				
PIONEER	DVJ-1000	Pro DJ - Turntable	GDJ-1500	G-Tour-T-Table			
PIONEER	DVJ-X1	Pro DJ - DVD Player	GDJ-1500	G-Tour-T-Table			
PIONEER	EFX1000	Pro DJ - Mixer	G-TOUR 12X17				
PIONEER	EFX500	Pro DJ - Mixer	G-MIX-B 1212	G-TOUR 12X17	G-Tour-CD-9x12	G-Tour-CDMX9x12	
PIONEER	PDP 505CMX	LCD/Plasma	G-TourLCDP50				
PIONEER	PDP 5070HD	LCD/Plasma	G-TourLCDP50				
PIONEER	PDP 6070	LCD/Plasma	G-TourLCDP60				
PIONEER	PDP 6100	LCD/Plasma	G-TourLCDP60				
PIONEER	PDP-4050HD	LCD/Plasma	G-TourLCDP50				
PIONEER	PDP-4304	LCD/Plasma	G-TourLCDP3743				
PIONEER	PDP-4330HD	LCD/Plasma	G-TourLCDP3743				
PIONEER	PDP-4330HD W/SPKS	LCD/Plasma	G-TourLCDP50				
PIONEER	PDP-433CMX	LCD/Plasma	G-TourLCDP3743				
PIONEER	PDP-501	LCD/Plasma	G-TourLCDP50				
PIONEER	PDP-502	LCD/Plasma	G-TourLCDP50				
PIONEER	PDP-502MX	LCD/Plasma	G-TourLCDP50				
PIONEER	PDP-5030HD	LCD/Plasma	G-TourLCDP50				
PIONEER	PDP-503CMX	LCD/Plasma	G-TourLCDP50				
PIONEER	PDP-5040HD	LCD/Plasma	G-TourLCDP50				
PIONEER	PDP-505HD	LCD/Plasma	G-TourLCDP50				
PIONEER	PDP-50MXE	LCD/Plasma	G-TourLCDP50				
PIONEER	PRO-1110HD	LCD/Plasma	G-TourLCDP50				
PLUS	U2-1200	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
PLUS	U5-111	Projector	GAV-1412R				
PLUS	U5-112	Projector	GAV-1412R				
PLUS	U5132	Projector	GAV-1412R				
PLUS	U5-232	Projector	GAV-1412R				
PLUS	U5-332	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
PROXIMA	9250	Projector	G-TourCarryOnFO				
PYLE PRO	PYD-710	Pro DJ - Mixer	G-Tour-CD-9x12	G-Tour-CDMX9x12			
PYLE-PRO	PYD1010	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CD-13x17	G-Tour-CDMX13x17	
PYLE-PRO	PYD1015	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CD-13x17	G-Tour-CDMX13x17	
PYLE-PRO	PYD1020	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CD-13x17	G-Tour-CDMX13x17	

Gator Cases Master Cross Reference

Updated 9/19/07

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
PYLE-PRO	PYD1910	Pro DJ - Mixer	G-MIX-L 1224	G-MIX 12 x24			
PYLE-PRO	PYD1920	Pro DJ - Mixer	G-MIX-L 1224	G-MIX 12 x24			
PYLE-PRO	PYD720	Pro DJ - Mixer	G-MIX-B 1212	G-Tour-CD-9x12	G-Tour-CDMX9x12		
RANDALL	R412CB	Guitar Speaker Cab	G-Tour 4x12				
RANDALL	R412CX	Guitar Speaker Cab	G-Tour 4x12				
RANDALL	RH150DG3	Amp Head	G-901	G-TOUR-AMP HEAD			
RANDALL	RM100M1	Amp Head	G-TOUR-AMP HEAD				
RANDALL	RM100M2	Amp Head	G-TOUR-AMP HEAD				
RANDALL	TITAN 412	Guitar Speaker Cab	G-Tour 4x12				
RANE	GRANDMASTER FLASH	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CD-13x17	G-Tour-CDMX13x17	
RANE	TOURING/CLUB MIXER	Pro DJ - Mixer	GMC-2222				
RANE	TTM56	Pro DJ - Mixer	G-Tour-CD-13x17	G-Tour-CDMX13x17	G-TOUR 12X17		
RANE	TTM57SL	Pro DJ - Mixer	G-Tour-CD-13x17	G-Tour-CDMX13x17	G-TOUR 12X17	GMC-2222	
RCA	PH50300	LCD/Plasma	G-TourLCDP50				
RCA	PH50400	LCD/Plasma	G-TourLCDP50				
RCA	PH50500	LCD/Plasma	G-TourLCDP50				
RCA	PR42300	LCD/Plasma	G-TourLCDP3743				
RCF	ART 310A	Speaker	GPA-600				
RCF	ART 312A	Speaker	GPA-700	GPA-777			
RCF	ART 322A	Speaker	GPA-700	GPA-777			
RCF	ART 522-A	Speaker	GPA-700	GPA-777			
RCF	ART 525-A	Speaker	GPA-700	GPA-777			
RCF	ART 705-AS	Speaker - Sub	G-Sub-2225-24 Bag				
RCF	CW5212	Speaker	GPA-777				
RCF	CW5215	Speaker	GPA-700				
RCF	SW4012	Speaker	GPA-600				
RENKUS-HEINZ	CF121M	Speaker	GPA-700				
REVOX	E-642	LCD/Plasma	G-TourLCDP3743				
REVOX	E-650	LCD/Plasma	G-TourLCDP50				
RMS	10-400S	Powered Mixer	GPA-720	GMC-2222			
RMS	6150R	Powered Mixer	GPA-720	GMC-2222			
ROLAND	CD2	Recording Workstation	G-MIX-B 1212	G-TOUR 12X17			
ROLAND	D2	Drum Machine	G-TOUR 12X17	GMC-2222			
ROLAND	DJ-2000	Sequencer	G-MIX-L 1622	GMC-2222			
ROLAND	DR880	Drum Machine	G-MIX-B 1212				
ROLAND	E09	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
ROLAND	E80	Keyboard	GKC-1648				
ROLAND	EXR-3	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
ROLAND	EXR46-OR	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
ROLAND	EXR-5	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
ROLAND	EXR-7	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	
ROLAND	FANTOM X6	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
ROLAND	FANTOM X7	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	
ROLAND	FANTOM X8	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	GKC-1648
ROLAND	FANTOM XA 61	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
ROLAND	FP-2	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	
ROLAND	FP4BK	Keyboard	GKB-88 Slim	GK-88	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim
ROLAND	FP4C-BK	Keyboard	GKB-88 Slim	GK-88	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim
ROLAND	FP4C-WT	Keyboard	GKB-88 Slim	GK-88	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim
ROLAND	FP4WH	Keyboard	GKB-88 Slim	GK-88	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim
ROLAND	FP-5	Keyboard	GKB-76	GK-76	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim
ROLAND	FP-5C	Keyboard	GKB-76	GK-76	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim
ROLAND	FP-7	Keyboard	GKB-88	GKB-88 Slim	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim
ROLAND	G-70	Keyboard	GKB-76	GK-76	GK-276R	GKC-1648	
ROLAND	GR-33	Guitar Multi-Effects	GK-2110				
ROLAND	GW-7	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
ROLAND	JUNO D 61	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
ROLAND	MC-307	Sequencer	G-TOUR 12X17	GMC-2222			
ROLAND	MC-808	Sampler	G-MIX-L 1618	G-MIX-L 1622	G-MIX 17 x 18	GMC-2222	
ROLAND	MC-909	Sequencer	G-MIX-L 1622	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222
ROLAND	MV-8000	Sampler	G-MIX-B 2020	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222	
ROLAND	MV-8800	Recording Workstation	G-MIX-B 2020	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222
ROLAND	PD105WT	Drum Machine	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	
ROLAND	RD-170	Keyboard	GKB-88	GK-88			
ROLAND	RD-300SX	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	
ROLAND	RD-70	Keyboard	GK-288R	G-Tour 88	GKC-1648		
ROLAND	RD-700SX	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	
ROLAND	RS-50	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
ROLAND	RS-70	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
ROLAND	SH-201	Keyboard	GKB-49	GK-49			
ROLAND	SH210	Keyboard	GKB-49	GK-49			
ROLAND	SH-32	Sequencer	G-MIX-B 1212	G-TOUR 12X17			
ROLAND	SP-606	Sampler	G-TOUR 12X17	GMC-2222			
ROLAND	SPD-S	Sampler	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	
ROLAND	TD-20	Drum Brain	G-TOUR 12X17	GMC-2222			
ROLAND	V SYNTH	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
ROLAND	V SYNTH GT	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
ROLAND	VA-76	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	GKC-1648
ROLAND	VK8	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	
ROLAND	VP-550	Keyboard	GKB-49	GK-49			
ROLAND	VR760	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	GKC-1648
ROLAND	VS-1824CD	Recording Workstation	G-MIX-L 1622	GMC-2222	GMC-3333		
ROLAND	VS-2000CD	Recording Workstation	G-MIX-L 1622	G-MIX-L 1822	G-MIX 19X21	G-TOUR 19X21	GMC-2222
ROLAND	VS-2400CD	Recording Workstation	G-MIX-B 2020	G-MIX 19X21	G-TOUR 19X21	GMC-2222	
ROLAND	VS2480CD	Recording Workstation	G-MIX 20 x 25	G-MIX 20 x 30	G-TOUR 20 x 25	G-TOUR 20 x 30	GMC-3333
ROLAND	VS2480DVD	Recording Workstation	GMC-3333	GMC-4221			
ROLAND	VS2480M	Recording Workstation	G-MIX 20 x 25	G-MIX 20 x 30	G-TOUR 20 x 25	G-TOUR 20 x 30	GMC-3333

Gator Cases Master Cross Reference
 Updated 9/19/07

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
RUNCO	PL-50C	LCD/Plasma	G-TourLCDP50				
SAMPO	PME-42S6	LCD/Plasma	G-TourLCDP3743				
SAMPO	PME-42V8	LCD/Plasma	G-TourLCDP50				
SAMPO	PME-42X6	LCD/Plasma	G-TourLCDP3743				
SAMPO	PME-50X6	LCD/Plasma	G-TourLCDP50				
SAMSON	DB1500A	Speaker - Sub	G-Sub-2225-24 Bag				
SAMSON	DB1800A	Speaker - Sub	G-Sub-2225-24 Bag				
SAMSON	MDR10	Mixer	G-MIX-B 1818	G-MIX-L 1822	G-MIX 17 x 18	G-MIX 19X21	GMC-2222
SAMSON	MDR1064	Mixer	G-MIX-B 1515	G-MIX 17 x 18	GMC-2222		
SAMSON	MDR16	Mixer	G-MIX 20 x 25	G-MIX 20 x 30	G-TOUR 20 x 25	G-TOUR 20 x 30	GMC-3333
SAMSON	MDR6	Mixer	G-MIX-B 1212				
SAMSON	MDR8	Mixer	G-MIX-B 1212	G-MIX-B 1515	G-TOUR 12X17	GMC-2222	
SAMSON	MIXPAD 12	Mixer	G-TOUR 12X17				
SAMSON	MIXPAD 9	Mixer	G-MIX-B 1212				
SAMSON	RB10S	Studio Monitor	GPA-720	GMC-2222			
SAMSON	RESOLV 120A	Studio Monitor	GMC-2222				
SAMSON	RESOLV SUB88	Studio Monitor	GMC-2222				
SAMSON	RS15S	Speaker - Sub	G-Sub-2225-24 Bag				
SAMSON	RS18S	Speaker - Sub	G-Sub-2225-24 Bag				
SAMSON	TM 300	Mixer	G-MIX 19X21	G-TOUR 19X21	GMC-2222		
SAMSON	TM 500	Mixer	G-MIX 19X21	G-TOUR 19X21	GMC-2222		
SAMSON	TXM16	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222		
SAMSON	TXM20	Mixer	GMC-2222	GMC-3333			
SAMSON	XM410	Powered Mixer	GMC-2222	GMC-3333			
SAMSON	XM610	Powered Mixer	GMC-2222	GMC-3333			
SAMSON	XM910	Powered Mixer	GMC-2222	GMC-3333			
SAMSUNG	204BW	LCD/Plasma	G-MIX-L 1622	G-TourLCDP2023			
SAMSUNG	206BW	LCD/Plasma	G-MIX-L 1622	G-TourLCDP2023			
SAMSUNG	HPL-5025	LCD/Plasma	G-TourLCDP50				
SAMSUNG	HPN-4239	LCD/Plasma	G-TourLCDP3743				
SAMSUNG	HPN5039	LCD/Plasma	G-TourLCDP50				
SAMSUNG	HP-R5052	LCD/Plasma	G-TourLCDP50				
SAMSUNG	HP-S5053	LCD/Plasma	G-TourLCDP50				
SAMSUNG	LN-R1550	LCD/Plasma	G-MIX-L 1822	G-TourLCDP2023			
SAMSUNG	PDP-50VG	LCD/Plasma	G-TourLCDP50				
SAMSUNG	PPM-42M5S	LCD/Plasma	G-TourLCDP3743				
SAMSUNG	PPM-42S3	LCD/Plasma	G-TourLCDP3743				
SAMSUNG	PPM-50H2	LCD/Plasma	G-TourLCDP50				
SAMSUNG	PPM-50H3	LCD/Plasma	G-TourLCDP50				
SAMSUNG	PPM50M5H	LCD/Plasma	G-TourLCDP50				
SAMSUNG	SPD-50P2	LCD/Plasma	G-TourLCDP50				
SAMSUNG	SPL-4225	LCD/Plasma	G-TourLCDP3743				
SAMSUNG	SPN-4235	LCD/Plasma	G-TourLCDP3743				
SANYO	PDP-42H1AN	LCD/Plasma	G-TourLCDP3743				
SANYO	PLC-SU51	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SANYO	PLC-SW30	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnPL		
SANYO	PLC-SW35	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnPL		
SANYO	PLC-X25A	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SANYO	PLC-XT11	Projector	G-TourCarryOnFO				
SANYO	PLC-XT16	Projector	G-TourCarryOnFO				
SANYO	PLC-XU100	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	G-TourCarryOnFO	G-TourCarryOnPL
SANYO	PLC-XU41	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SANYO	PLC-XU47	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SANYO	PLC-XU48	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SANYO	PLC-XU51	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SANYO	PLC-XU55A	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SANYO	PLC-XU56	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SANYO	PLC-XU58	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SANYO	PLC-XU60	Projector	G-TourCarryOnFO				
SANYO	PLC-XU73	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SANYO	PLC-XU83	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	G-TourCarryOnFO	G-TourCarryOnPL
SANYO	PLC-XU86	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SANYO	PLCXW55	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SANYO	PLV-Z2	Projector	GAV-1813R	G-TourCarryOnFO			
SELT	MPD-5010A	LCD/Plasma	G-TourLCDP50				
SHARP	AQUOS LC-32D40U	LCD/Plasma	G-TourLCDP2632				
SHARP	LC-20D30U	LCD/Plasma	G-MIX-L 1622	G-MIX-L 1822	G-TourLCDP2023		
SHARP	LC-26DV20U	LCD/Plasma	G-TourLCDP2632				
SHARP	LC-37HV4U	LCD/Plasma	G-TourLCDP3743				
SHARP	LC-45GD4U	LCD/Plasma	G-TourLCDP3743				
SHARP	LC-PD50U	LCD/Plasma	G-TourLCDP50				
SHARP	PG-A20X	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SHARP	PG-B10S	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SHARP	PG-MB60X	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-1813R	G-TourCarryOnFO
SHARP	X-20-X	Projector	G-TourCarryOnFO				
SM PRO AUDIO	D14	Mixer	G-MIX-B 1212				
SM PRO AUDIO	D18	Mixer	G-MIX-B 1212				
SOFTBOARD	502	LCD/Plasma	G-TourLCDP50				
SOFTBOARD	503	LCD/Plasma	G-TourLCDP50				
SOFTBOARD	512	LCD/Plasma	G-TourLCDP3743				
SOFTBOARD	513	LCD/Plasma	G-TourLCDP3743				
SOFTBOARD	522	LCD/Plasma	G-TourLCDP3743				
SOLDANO	4X12 SL CAB	Guitar Speaker Cab	G-Tour 4x12				
SOLDANO	SLO100 HEAD	Amp Head	G-901				
SONY	BRAVIA KDL-V32XBR2	LCD/Plasma	G-TourLCDP2632				
SONY	DMXP01	Pro DJ - Mixer	G-MIX-B 1212	G-Tour-CD-9x12	G-Tour-CDMX9x12	GDJ-i-GO	
SONY	FWD32LX2F/B	LCD/Plasma	G-TourLCDP2632				

Gator Cases Master Cross Reference
Updated 9/19/07

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
SONY	FWD32LX2F/S	LCD/Plasma	G-TourLCDP2632				
SONY	FWD40LX2F/B	LCD/Plasma	G-TourLCDP3743				
SONY	FWD40LX2F/S	LCD/Plasma	G-TourLCDP3743				
SONY	FWD-50PX2/B	LCD/Plasma	G-TourLCDP50				
SONY	FWD50PX2/B	LCD/Plasma	G-TourLCDP50				
SONY	FWD-50PX2/S	LCD/Plasma	G-TourLCDP50				
SONY	FWD50PX2/S	LCD/Plasma	G-TourLCDP50				
SONY	PFM-42B1	LCD/Plasma	G-TourLCDP3743				
SONY	PFM-42B2H	LCD/Plasma	G-TourLCDP3743				
SONY	PFM-42B2U	LCD/Plasma	G-TourLCDP3743				
SONY	PFM-42V1	LCD/Plasma	G-TourLCDP3743				
SONY	PFM-42V1-B	LCD/Plasma	G-TourLCDP3743				
SONY	PFM-42X1	LCD/Plasma	G-TourLCDP3743				
SONY	PFM500A2WU	LCD/Plasma	G-TourLCDP3743				
SONY	PFM500A3WU	LCD/Plasma	G-TourLCDP3743				
SONY	PFM-50C1	LCD/Plasma	G-TourLCDP50				
SONY	PFM510A2WU	LCD/Plasma	G-TourLCDP3743				
SONY	PSLX250H	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
SONY	PWD-42LX1/B	LCD/Plasma	G-TourLCDP3743				
SONY	SWD-50PX1-B	LCD/Plasma	G-TourLCDP50				
SONY	VAIO A140	Laptop	GK-LT25W	GRC-STUDIO-2-GO	GRC-STUDIO-4-GC	GAV-1813R	
SONY	VAIO A250	Laptop	GK-LT25W	GSR-2U AV	GSRW-2U AV	GRC-STUDIO-2-GC	GAV-1813R
SONY	VAIO AR	Laptop	GK-LT25W	GSRW-2U AV	GRC-STUDIO-2-GC	GAV-1813R	
SONY	VAIO C	Laptop	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SONY	VAIO FE	Laptop	GK-LT25W	G-TourCarryOnPL	GRC-STUDIO-2-GC	GRC-STUDIO-4-GC	GAV-1813R
SONY	VAIO FJ	Laptop	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SONY	VAIO FS	Laptop	GK-LT25W	G-TourCarryOnPL	GRC-STUDIO-2-GC	GRC-STUDIO-4-GC	GAV-1813R
SONY	VAIO K35	Laptop	GK-LT25W	GAV-1813R			
SONY	VAIO K37	Laptop	GK-LT25W	GAV-1813R			
SONY	VAIO S150	Laptop	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SONY	VAIO S360P	Laptop	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SONY	VAIO T140P/L	Laptop	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	GAV-DLX-20
SONY	VAIO T150/L	Laptop	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	GAV-DLX-20
SONY	VAIO TX	Laptop	GAV-20	GAV-DLX-20			
SONY	VAIO VGN	Laptop	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SONY	VPL-CS7	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SONY	VPL-CX70	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SONY	VPL-CX75	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SONY	VPL-CX80	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-1813R	G-TourCarryOnFO
SONY	VPL-CX85	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-1813R	G-TourCarryOnFO
SONY	VPL-DS100	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SONY	VPL-ES2	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SONY	VPL-EX1	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
SOUNDCRAFT	COMPACT 10	Mixer	G-MIX-L 1224	G-MIX 12 x24			
SOUNDCRAFT	COMPACT 4	Mixer	G-MIX-B 1212				
SOUNDCRAFT	EPM12	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222	GMC-3333	
SOUNDCRAFT	EPM6	Mixer	GMC-2222				
SOUNDCRAFT	EPM8	Mixer	GMC-2222				
SOUNDCRAFT	FX16	Mixer	G-MIX-B 2020	G-MIX-L 1822	G-MIX 19X21	G-TOUR 19X21	GMC-2222
SOUNDCRAFT	FX8	Mixer	G-MIX-B 1818	G-MIX-L 1822	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
SOUNDCRAFT	GB2-16	Mixer	GMC-3333				
SOUNDCRAFT	GB4-12	Mixer	GMC-3333				
SOUNDCRAFT	GIGRAC 1000	Powered Mixer	GPA-720	GMC-2222			
SOUNDCRAFT	GIGRAC 1000ST	Mixer	G-TOUR 12X17	GMC-2222			
SOUNDCRAFT	GIGRAC 600	Powered Mixer	GMC-2222				
SOUNDCRAFT	K1-16	Mixer	GMC-3333				
SOUNDCRAFT	K1-8	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222	GMC-3333	
SOUNDCRAFT	LX7	Mixer	G-MIX 24 x 36	G-TOUR 24 x 36	GMC-4221		
SOUNDCRAFT	LX7II-16	Mixer	G-TOUR 20 x 30	GMC-3333	GMC-4221		
SOUNDCRAFT	LX7II-24	Mixer	G-MIX 24 x 36	G-TOUR 24 x 36	GMC-4221		
SOUNDCRAFT	LX7II-32	Mixer	G-MIX 22 x 46	GMC-4221			
SOUNDCRAFT	MPM12 (NO SIDE PANELS)	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
SOUNDCRAFT	MPM20	Mixer	G-MIX 20 x 30	G-TOUR 20 x 30	GMC-3333	GMC-4221	
SOUNDCRAFT	NOTEPAD	Mixer	G-MIX-B 1212				
SOUNDCRAFT	POWERPAD	Mixer	G-MIX-B 1212				
SOUNDCRAFT	SPIRIT 1200	Mixer	GMC-3333	GMC-4221			
SOUNDCRAFT	SPIRIT E12	Mixer	G-MIX-L 1822	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222
SOUNDCRAFT	SPIRIT E6	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
SOUNDCRAFT	SPIRIT E8	Mixer	G-MIX-B 1818	G-MIX-L 1822	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
SOUNDCRAFT	SPIRIT ES	Mixer	G-MIX-L 1822	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222
SOUNDCRAFT	SPIRIT FX16	Mixer	G-MIX-B 2020	G-MIX-L 1822	G-MIX 19X21	G-TOUR 19X21	GMC-2222
SOUNDCRAFT	SPIRIT FX8	Mixer	G-MIX-B 1818	G-MIX-L 1822	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
SOUNDCRAFT	SPIRIT M12	Mixer	G-MIX-B 2020	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222
SOUNDCRAFT	SPIRIT M4	Mixer	G-MIX-L 1622	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222
SOUNDCRAFT	SPIRIT M8	Mixer	G-MIX-B 2020	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222
SOUNDCRAFT	SX 12	Mixer	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	G-TOUR 20 x 25	GMC-2222
SOUNDCRAFT	UREI 1601	Pro DJ - Mixer	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	G-Tour-CD-13x17	G-Tour-CDMX13x17
SOUNDTECH	1604	Mixer	G-MIX-L 1618	G-MIX 17 x 18	G-MIX 19X21	G-TOUR 19X21	GMC-2222
STANTON	C-302	Pro DJ - CD Player	G-Tour-CD-13x17	G-Tour-CDMX13x17			
STANTON	C-303	Pro DJ - CD Player	G-Tour-CD-13x17	G-Tour-CDMX13x17			
STANTON	C313	Pro DJ - CD Player	G-Tour-CD-13x17	G-Tour-CDMX13x17			
STANTON	C314	Pro DJ - CD Player	G-Tour-CD-13x17	G-Tour-CDMX13x17			
STANTON	CM-203	Pro DJ - Mixer	GMC-2222				
STANTON	CM-205	Pro DJ - Mixer	GMC-2222				
STANTON	M-201	Pro DJ - Mixer	G-MIX-B 1212				
STANTON	M-202	Pro DJ - Mixer	G-MIX-B 1212				
STANTON	M-303	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222			

Gator Cases Master Cross Reference

Updated 9/19/07

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
STANTON	M-304	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222			
STANTON	M-505	Pro DJ - Mixer	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	G-Tour-CDMX13x17
STANTON	RM-3	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CD-13x17	G-Tour-CDMX13x17	
STANTON	RM-3S	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CD-13x17	G-Tour-CDMX13x17	
STANTON	S-250	Pro DJ - CD Player	G-Tour-CD-9x12	G-Tour-CDMX9x12	GDJ-DJ Case		
STANTON	S300	Pro DJ - CD Player	G-Tour-CD-9x12	G-Tour-CDMX9x12			
STANTON	SA-12	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222			
STANTON	SA-3	Pro DJ - Mixer	G-TOUR 12X17				
STANTON	SA-5	Pro DJ - Mixer	G-Tour-CD-13x17	G-Tour-CDMX13x17	G-TOUR 12X17		
STANTON	SA-8	Pro DJ - Mixer	G-TOUR 12X17				
STANTON	SK-2	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CDMX9x12		
STANTON	SK-2F	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CDMX9x12		
STANTON	SK-5	Pro DJ - Mixer	G-MIX-B 1212	G-Tour-CD-9x12	G-Tour-CDMX9x12		
STANTON	SK-6	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CDMX9x12		
STANTON	SK-6F	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CDMX9x12		
STANTON	SK-ONE	Pro DJ - Mixer	GDJ-DJ Case				
STANTON	SMX-201	Pro DJ - Mixer	G-MIX-B 1212	G-Tour-CD-9x12	G-Tour-CDMX9x12		
STANTON	SMX-211	Pro DJ - Mixer	G-MIX-B 1212	G-Tour-CD-9x12	G-Tour-CDMX9x12		
STANTON	SMX-301	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222			
STANTON	SMX-401	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222			
STANTON	SMX-501	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222			
STANTON	ST-100	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
STANTON	ST-90	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
STANTON	STR8-100	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
STANTON	STR8-20	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
STANTON	STR8-30	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
STANTON	STR8-50	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
STANTON	STR8-60	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
STANTON	STR8-80	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
STANTON	STR8-90	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
STANTON	T50	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
STANTON	T60	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
STANTON	T80	Pro DJ - Turntable	GDJ-1500	GDJ-2500	G-Tour-T-Table		
STUDIO LOGIC	SL 990XP	Keyboard	GKB-88 Slim	GK-88	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim
STUDIO LOGIC	VMK149	Keyboard	GKB-49	GK-49			
STUDIO LOGIC	VMK188	Keyboard	GKB-88 Slim	GK-88	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim
STUDIO LOGIC	SL161PRO	Keyboard	GKB-49	GK-49	GK-4212		
STUDIO LOGIC	SL880PRO	Keyboard	GKB-88 Slim	GK-88	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim
STUDIOMASTER	C1	Mixer	G-TOUR 12X17				
STUDIOMASTER	CSX	Mixer	G-MIX-B 2020	G-MIX-L 1622	G-MIX 19X21	G-TOUR 19X21	GMC-2222
STUDIOMASTER	PAX10	Speaker	GPA-600				
STUDIOMASTER	VPX12	Speaker	GPA-700	GPA-777			
STUDIOMASTER	VX12	Speaker	GPA-700	GPA-600			
STUDIOMASTER	VX15SUB	Speaker - Sub	GPA-700	GPA-777	G-Sub-2225-24 Bag		
SUNN	T50C	Combo Amp 1x12	G-212A	G-TOUR 2226	G-TOUR 2430		
SUZUKI	SP-37	Keyboard	GKB-49	GK-49	GK-261R	G-Tour 61	GKC-1540
SUZUKI	SP-67	Keyboard	GKB-49	GK-49	GK-261R	G-Tour 61	GKC-1540
SVA	HD4208T11	LCD/Plasma	G-TourLCDP50				
TANNOY	ELLIPSE112ID	Studio Monitor	GMC-2222				
TANNOY	ELLIPSE212ID	Studio Monitor	GMC-2222				
TANNOY	TS12	Studio Monitor	GMC-2222				
TAPCO	6918S	Speaker - Sub	G-Sub-2225-24 Bag				
TAPCO	BLEND 6	Mixer	G-MIX-B 1212				
TAPCO	MIX100	Mixer	G-MIX-B 1212				
TAPCO	MIX120	Mixer	G-MIX-B 1212	GMC-2222			
TAPCO	MIX220FX	Mixer	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	
TAPCO	MIX260FX	Mixer	G-MIX-B 1515	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
TAPCO	SW10	Studio Monitor	GMC-2222				
TAPCO	TH-15A	Speaker	GPA-700				
TASCAM	2488	Recording Workstation	G-MIX-L 1822	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222	GMC-3333
TASCAM	414 MKII	Recording Workstation	G-TOUR 12X17				
TASCAM	424 MKII	Recording Workstation	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
TASCAM	DM24	Mixer	GMC-3333				
TASCAM	DM3200	Mixer	GMC-3333				
TASCAM	DP-01	Recording Workstation	G-MIX-L 1618	G-MIX-L 1622	G-MIX 17 x 18	GMC-2222	
TASCAM	DP01FX	Recording Workstation	G-MIX-L 1622	GMC-2222			
TASCAM	DP-01FXCD	Recording Workstation	G-MIX-L 1618	G-MIX-L 1622	G-MIX 17 x 18	GMC-2222	
TASCAM	FW-1082	Recording Interface	G-MIX-L 1622	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222
TASCAM	FW-1884	Recording Workstation	G-MIX 20 x 25	G-MIX 20 x 30	G-TOUR 20 x 25	G-TOUR 20 x 30	GMC-3333
TASCAM	MF-P01	Recording Workstation	G-MIX-B 1212	G-TOUR 12X17			
TASCAM	PORTA 02	Recording Workstation	G-MIX-B 1212	G-TOUR 12X17			
TASCAM	PORTA 02MKII	Recording Workstation	G-MIX-B 1212	G-TOUR 12X17			
TASCAM	US-428	Recording Interface	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	GK-L725W
TATUN	P42B5MT	LCD/Plasma	G-TourLCDP3743				
TC ELECTRONICS	G-SYSTEM	Guitar Multi-Effects	G-MIX 12 x24				
TECHNICS	SH-EX1200	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CDMX9x12		
TECHNICS	SH-MZ1200	Pro DJ - Mixer	G-MIX-B 1515	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222	G-Tour-CDMX13x17
TECHNICS	SL1210M5G	Pro DJ - Turntable	GDJ-2500				
THD	2X12 CAB	Guitar Speaker Cab	G-212A	G-TOUR 2430			
TLAUDIO	M416	Mixer	GMC-3333				
TOPAZ	S18-4	Mixer	G-MIX-B 2020	G-MIX-L 1822	G-MIX 19X21	G-TOUR 19X21	GMC-2222
TOPAZ	S28-4	Mixer	GMC-3333	GMC-4221			
TOSHIBA	42WP27B	LCD/Plasma	G-TourLCDP3743				
TOSHIBA	50HP66	LCD/Plasma	G-TourLCDP50				
TOSHIBA	50WP27B	LCD/Plasma	G-TourLCDP50				
TOSHIBA	PORTEGE R100	Laptop	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
TOSHIBA	QOSMIO G20	Laptop	GK-L725W	GSR-2U AV	GSRW-2U AV	GRC-STUDIO-2-GC	GAV-1813R

Gator Cases Master Cross Reference
Updated 9/19/07

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
TOSHIBA	SATELLITE M35X	Laptop	GK-LT25W	G-TourCarryOnPL	GRC-STUDIO-2-GC	GRC-STUDIO-4-GC	GAV-1813R
TOSHIBA	SATELLITE 2435-S255	Laptop	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GRC-STUDIO-2-GC	GRC-STUDIO-4-GO
TOSHIBA	SATELLITE A105	Laptop	GK-LT25W	G-TourCarryOnPL	GRC-STUDIO-2-GC	GRC-STUDIO-4-GC	GAV-1813R
TOSHIBA	SATELLITE A25	Laptop	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GRC-STUDIO-2-GC	GRC-STUDIO-4-GO
TOSHIBA	SATELLITE A45	Laptop	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GRC-STUDIO-2-GC	GRC-STUDIO-4-GO
TOSHIBA	SATELLITE A75	Laptop	GK-LT25W	GRC-STUDIO-2-GO	GRC-STUDIO-4-GC	GAV-1813R	
TOSHIBA	SATELLITE M35	Laptop	GK-LT25W	G-TourCarryOnPL	GRC-STUDIO-2-GC	GRC-STUDIO-4-GC	GAV-1813R
TOSHIBA	SATELLITE P25	Laptop	GK-LT25W	GSR-2U AV	GSRW-2U AV	GRC-STUDIO-2-GC	GRC-STUDIO-4-GO
TOSHIBA	SATELLITE PRO M15-S405	Laptop	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GRC-STUDIO-2-GC	GRC-STUDIO-4-GO
TOSHIBA	SATELLITE R15	Laptop	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R		
TOSHIBA	TDP-MT500	Projector	G-TourCarryOnFO				
TOSHIBA	TDP-S20U	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
TOSHIBA	TDP-SW80U	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	G-TourCarryOnFO	G-TourCarryOnPL
TURBOSOUND	TXD-118	Speaker - Sub	G-Sub-2225-24 Bag				
UNIVERSAL	42	LCD/Plasma	G-TourLCDP3743				
UNIVERSAL	MVP 2420	LCD/Plasma	G-TourLCDP3743				
VESTAX	CDX-05	Pro DJ - Mixer	G-MIX-B 1212	G-TOUR 12X17	G-Tour-CDMX9x12		
VESTAX	PCV-275	Pro DJ - Mixer	G-MIX-L 1224	G-MIX 12 x24			
VESTAX	PMC-007	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CDMX13x17		
VESTAX	PMC-05PRO III	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CDMX13x17		
VESTAX	PMC-05PRO SL	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CDMX13x17		
VESTAX	PMC-07	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CDMX13x17		
VESTAX	PMC-37 PRO	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CDMX13x17		
VESTAX	VMC-002	Pro DJ - Mixer	G-MIX-B 1212	GMC-2222	G-Tour-CDMX9x12		
VESTAX	VMC-185	Pro DJ - Mixer	G-MIX 17 x 18	G-TOUR 12X17	GMC-2222		
VESTEX	BDT2500	Pro DJ - Turntable	GDJ-1500				
VESTEX	HANDY TRAX	Pro DJ - Turntable	G-Tour-CD-13x17	G-Tour-CDMX13x17			
VESTEX	PCV150	Pro DJ - Mixer	G-MIX-L 1224				
VESTEX	PDX2000MK2	Pro DJ - Turntable	GDJ-2500				
VESTEX	PDX2000MK2PRO	Pro DJ - Turntable	GDJ-2500				
VESTEX	PDX2300	Pro DJ - Turntable	GDJ-2500				
VESTEX	PDX2300MK2PRO	Pro DJ - Turntable	GDJ-2500				
VESTEX	PMC07PRO	Pro DJ - Mixer	G-TOUR 12X17	GMC-2222	G-Tour-CDMX13x17		
VIEWSONIC	CINE1000	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
VIEWSONIC	CINE5000	Projector	G-TourCarryOnFO				
VIEWSONIC	N2060W	LCD/Plasma	G-MIX-L 1622	G-MIX-L 1822	G-TourLCDP2023		
VIEWSONIC	PJ400	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
VIEWSONIC	PJ402D	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnPL		
VIEWSONIC	PJ452	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
VIEWSONIC	PJ458D	Projector	GAV-20	GAV-DLX-20	G-TourCarryOnPL		
VIEWSONIC	PJ506D	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
VIEWSONIC	PJ558D	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
VIEWSONIC	PJ656	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
VIEWSONIC	PJ658	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
VIEWSONIC	PJ766D	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
VIEWSONIC	PJ862	Projector	GAV-1412R	GAV-DLX-1412R	GAV-PE-1412R	GAV-20	G-TourCarryOnPL
VIEWSONIC	VPW-4255	LCD/Plasma	G-TourLCDP3743				
VIEWSONIC	VPW-505	LCD/Plasma	G-TourLCDP50				
VOX	AC100CPH	Amp Head	G-901	G-TOUR-AMP HEAD			
VOX	AC15CC1	Combo Amp 1x12	G-212A				
VOX	AC15CC1X	Combo Amp 1x12	G-212A				
VOX	AC15H1TV LTD	Combo Amp 1x12	G-TOUR 2226				
VOX	AC15H1TVL	Combo Amp 1x12	G-TOUR 2226				
VOX	AC30BM	Combo Amp 2x12	G-212A	G-TOUR 2430			
VOX	AC30CC1	Combo Amp 1x12	G-212A	G-TOUR 2226	G-TOUR 2430		
VOX	AC30CC2	Combo Amp 2x12	G-212A	G-TOUR 2430			
VOX	AC30CC2X	Combo Amp 2x12	G-212A	G-TOUR 2430			
VOX	AC30CCH	Amp Head	G-901				
VOX	AC50CP2	Combo Amp 2x12	G-212A	G-TOUR 2430			
VOX	AD100VT	Combo Amp 2x12	G-212A	G-TOUR 2430			
VOX	AD120VTH	Amp Head	G-212A	G-TOUR 2430			
VOX	AD120VTX NEODOG	Combo Amp 2x12	G-212A	G-TOUR 2430			
VOX	AD212	Guitar Speaker Cab	G-212A	G-TOUR 2430			
VOX	AD50VT	Combo Amp 1x12	G-112A	G-TOUR 2226			
VOX	AD60VTX NEODOG	Combo Amp 1x12	G-TOUR 2226				
VOX	V212BN	Guitar Speaker Cab	G-212A	G-TOUR 2430			
VOX	V212BNX	Guitar Speaker Cab	G-212A	G-TOUR 2430			
VOX	V412BK	Guitar Speaker Cab	G-Tour 4x12				
VOX	V412BN	Guitar Speaker Cab	G-Tour 4x12				
WESTINGHOUSE	LTV-20V4	LCD/Plasma	G-TourLCDP2023				
WESTINGHOUSE	LTV-32W4	LCD/Plasma	G-TourLCDP2632				
WHARFEDALE	LA15P	Speaker	GPA-700				
WHARFEDALE	LA15PB	Speaker	GPA-700				
WHARFEDALE	TITAN 12	Speaker - Sub	GPA-600				
WHARFEDALE	TITAN 15	Speaker	GPA-700				
YAMAHA	01V	Mixer	G-MIX-L 1822	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222	GMC-3333
YAMAHA	01V96	Mixer	G-MIX-L 1822	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222	GMC-3333
YAMAHA	01X	Digital Interface	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
YAMAHA	02R96V2	Recording Interface	GMC-3333				
YAMAHA	A12M	Speaker - Sub	GPA-700	GPA-600	GPA-777		
YAMAHA	A15	Speaker	GPA-700				
YAMAHA	AW1600	Recording Workstation	G-MIX-L 1622	G-MIX 19X21	G-TOUR 19X21	GMC-2222	
YAMAHA	AW16G	Recording Workstation	G-MIX-L 1618	G-MIX-L 1622	G-MIX 17 x 18	GMC-2222	
YAMAHA	AW2400	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222	GMC-3333	
YAMAHA	AW4416HDCD	Recording Workstation	G-MIX 20 x 25	G-MIX 20 x 30	G-TOUR 20 x 25	G-TOUR 20 x 30	GMC-3333
YAMAHA	BR10	Speaker	GPA-600				
YAMAHA	BR12	Speaker	GPA-700	GPA-600	GPA-777		

Gator Cases Master Cross Reference
Updated 9/19/07

Includes: Pro Audio, Audio/Visual, Keyboard, Recording, and DJ gear

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
YAMAHA	BR12M	Speaker	GPA-700	GPA-600	GPA-777		
YAMAHA	BR15	Speaker	GPA-700				
YAMAHA	BR15M	Speaker	GPA-700				
YAMAHA	C112V	Speaker	GPA-700	GPA-777			
YAMAHA	C115V	Speaker	GPA-700				
YAMAHA	CM10V	Speaker	GPA-600				
YAMAHA	CM12V	Speaker	GPA-700	GPA-777			
YAMAHA	CM15V	Speaker	GPA-700				
YAMAHA	CP300	Keyboard	GKC-1648				
YAMAHA	CP33	Keyboard	GKB-88 Slim	GK-88	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim
YAMAHA	DD65	Drum Machine	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-3333		
YAMAHA	DG-60	Combo Amp 1x12	G-112A	G-TOUR 2226			
YAMAHA	DG-80	Combo Amp 1x12	G-112A	G-TOUR 2226			
YAMAHA	DGX203	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	GKC-1648
YAMAHA	DGX305	Keyboard	GKC-1648				
YAMAHA	DGX505	Keyboard	GKC-1648				
YAMAHA	DJX 203	Keyboard	GKC-1540				
YAMAHA	EMX 212S	Powered Mixer	GPA-720	GMC-2222			
YAMAHA	EMX 312S	Powered Mixer	GPA-720	GMC-2222			
YAMAHA	EMX 5014C	Mixer	G-MIX-L 1822	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222
YAMAHA	EMX 5016CF	Mixer	G-MIX-L 1822	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222
YAMAHA	EMX 512S	Powered Mixer	GPA-720	GMC-2222			
YAMAHA	EMX 620	Powered Mixer	GPA-720	GMC-2222			
YAMAHA	EMX 640	Powered Mixer	GPA-720	GMC-2222			
YAMAHA	EMX 860ST	Powered Mixer	GPA-720	GMC-2222			
YAMAHA	EMX3000	Mixer	G-MIX-B 2020	G-MIX-L 1822	G-MIX 19X21	G-TOUR 19X21	GMC-2222
YAMAHA	EMX5000	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222	GMC-3333	
YAMAHA	EMX5000-12	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222	GMC-3333	
YAMAHA	EMX5000-20	Mixer	GMC-3333				
YAMAHA	EMX62M	Powered Mixer	GPA-720	GMC-2222			
YAMAHA	EMX66M	Powered Mixer	GPA-720	GMC-2222			
YAMAHA	EMX68S	Powered Mixer	GPA-720	GMC-2222			
YAMAHA	EMX88S	Powered Mixer	GPA-720	GMC-2222			
YAMAHA	EZ150	Keyboard	GKB-49	GK-49	GKC-1540		
YAMAHA	EZ250I	Keyboard	GKB-49	GK-49	GKC-1540		
YAMAHA	GF12/12	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	G-TOUR 20 x 30	GMC-3333	
YAMAHA	GF16/12	Mixer	G-TOUR 20 x 30	GMC-3333	GMC-4221		
YAMAHA	GF24/12	Mixer	G-MIX 22 x 46	GMC-4221			
YAMAHA	HS10W	Studio Monitor	GMC-2222				
YAMAHA	LS9-16	Mixer	GMC-2222				
YAMAHA	LS9-32	Mixer	GMC-4221				
YAMAHA	MD4S	Recording Workstation	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
YAMAHA	MD8	Recording Workstation	G-MIX-B 2020	G-MIX-L 1822	G-MIX 19X21	G-TOUR 19X21	GMC-2222
YAMAHA	MG10/2	Mixer	G-MIX-B 1212	G-TOUR 12X17			
YAMAHA	MG102C	Mixer	G-MIX-B 1212	G-TOUR 12X17	GMC-2222		
YAMAHA	MG12/4	Mixer	G-MIX-L 1618	G-MIX-L 1622	G-MIX 17 x 18	GMC-2222	
YAMAHA	MG12/4 FX	Mixer	G-MIX-L 1618	G-MIX-L 1622	G-MIX 17 x 18	GMC-2222	
YAMAHA	MG124C	Mixer	G-MIX-B 2020	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222
YAMAHA	MG124CX	Mixer	G-MIX-B 2020	G-MIX 19X21	G-MIX 20 x 25	G-TOUR 19X21	GMC-2222
YAMAHA	MG16/4	Mixer	G-MIX-B 1818	G-MIX-L 1822	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
YAMAHA	MG16/6FX	Mixer	G-MIX-B 1818	G-MIX-L 1822	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
YAMAHA	MG24/14	Mixer	G-MIX 24 x 36	G-TOUR 24 x 36			
YAMAHA	MG24/14FX	Mixer	G-MIX 24 x 36	G-TOUR 24 x 36	GMC-3333		
YAMAHA	MG32/14FX	Mixer	G-MIX 22 x 46				
YAMAHA	MG8/2FX	Mixer	G-MIX-B 1212	G-TOUR 12X17			
YAMAHA	MG82CX	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
YAMAHA	MM1242	Mixer	G-MIX-L 1618	G-MIX 17 x 18	GMC-2222		
YAMAHA	MM1402	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
YAMAHA	MM6	Keyboard	GKB-49	GK-49	GKC-1540		
YAMAHA	MO6	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
YAMAHA	MO8	Keyboard	GKC-1648				
YAMAHA	MOTIF ES6	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
YAMAHA	MOTIF ES7	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	GKC-1648
YAMAHA	MOTIF ES8	Keyboard	GK-288R	G-Tour 88	GKC-1648		
YAMAHA	MOTIF XS6	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
YAMAHA	MOTIF XS7	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	GKC-1648
YAMAHA	MOTIF XS8	Keyboard	GK-288R	G-Tour 88	GKC-1648		
YAMAHA	MOTIF6	Keyboard	GKB-61	GK-61	GK-261R	G-Tour 61	GKC-1540
YAMAHA	MOTIF8	Keyboard	GK-288R	G-Tour 88	GKC-1648		
YAMAHA	MSR800W	Speaker - Sub	G-Sub-2225-24 Bag				
YAMAHA	MV12/6	Mixer	GMC-2222				
YAMAHA	MV1602	Mixer	GMC-2222				
YAMAHA	MW10 USB	Mixer	G-MIX-B 1212	G-TOUR 12X17	GMC-2222		
YAMAHA	MW12 USB	Mixer	G-MIX-L 1618	G-MIX-L 1622	G-MIX 17 x 18	GMC-2222	
YAMAHA	MX12/4	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
YAMAHA	MX12/6	Mixer	G-MIX-B 1818	G-MIX-L 1618	G-MIX 17 x 18	G-TOUR 19X21	GMC-2222
YAMAHA	MX20/6	Mixer	G-MIX 20 x 30	G-TOUR 20 x 30	GMC-3333	GMC-4221	
YAMAHA	MX200-12	Mixer	G-MIX 20 x 25	G-TOUR 20 x 25	GMC-2222	GMC-3333	
YAMAHA	MX200-16	Mixer	G-MIX 20 x 30	G-TOUR 20 x 30	GMC-3333	GMC-4221	
YAMAHA	MX200-24	Mixer	G-MIX 22 x 46	GMC-4221			
YAMAHA	MX200-8	Mixer	G-MIX-B 2020	G-MIX-L 1822	G-MIX 19X21	G-TOUR 19X21	GMC-2222
YAMAHA	MX400-12	Mixer	GMC-3333				
YAMAHA	MX400-16	Mixer	GMC-3333				
YAMAHA	MX400-8	Mixer	GMC-3333				
YAMAHA	P120	Keyboard	GKB-88 Slim	GK-88	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim
YAMAHA	P120S	Keyboard	GKB-88 Slim	GK-88	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim
YAMAHA	P140	Keyboard	GKB-88 Slim	GK-88	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim

Manufacturer	Model	Type	Fits (1)	Fits (2)	Fits (3)	Fits (4)	Fits (5)
YAMAHA	P200	Keyboard	GK-288R	G-Tour 88	GKC-1648		
YAMAHA	P250	Keyboard	GK-288R	G-Tour 88	GKC-1648		
YAMAHA	P60	Keyboard	GKB-88 Slim	GK-88	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim
YAMAHA	P60S	Keyboard	GKB-88 Slim	GK-88	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim
YAMAHA	P70	Keyboard	GKB-88 Slim	GK-88	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim
YAMAHA	P90	Keyboard	GKB-88 Slim	GK-88 Slim	GK-288 Slim	G-Tour 88 Slim	
YAMAHA	PDM-1	LCD/Plasma	G-TourLCDP50				
YAMAHA	PF500	Keyboard	GKC-1648				
YAMAHA	PSR 293	Keyboard	GKB-49	GK-49	GKC-1540		
YAMAHA	PSR E203	Keyboard	GKB-49	GK-49	GKC-1540		
YAMAHA	PSR E303	Keyboard	GKB-49	GK-49	GKC-1540		
YAMAHA	PSR E404	Keyboard	GKC-1540				
YAMAHA	PSR1500	Keyboard	GKC-1540				
YAMAHA	PSR172	Keyboard	GKB-49	GK-49	GKC-1540		
YAMAHA	PSR273	Keyboard	GKB-49	GK-49	GKC-1540		
YAMAHA	PSR293	Keyboard	GKC-1540				
YAMAHA	PSR3000	Keyboard	GKB-61	GK-61	GKC-1540		
YAMAHA	PSR450	Keyboard	GKC-1540				
YAMAHA	PSR-E213	Keyboard	GKB-49	GK-49	GKC-1540		
YAMAHA	PSR-E313	Keyboard	GKB-49	GK-49	GKC-1540		
YAMAHA	PSR-E403	Keyboard	GKC-1540				
YAMAHA	PSRK1	Keyboard	GKC-1540				
YAMAHA	PSRS500	Keyboard	GKC-1540				
YAMAHA	S03	Keyboard	GK-4212	GK-261R	G-Tour 61		
YAMAHA	S08	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	GKC-1648
YAMAHA	S112V	Speaker	GPA-700	GPA-777			
YAMAHA	S115V	Speaker	GPA-700				
YAMAHA	S90	Keyboard	GK-288R	G-Tour 88	GKC-1648		
YAMAHA	S90ES	Keyboard	GK-288R	G-Tour 88	GKC-1648		
YAMAHA	SM12V	Speaker	GPA-700	GPA-777			
YAMAHA	SM15V	Speaker	GPA-700				
YAMAHA	STAGEPAS 500	Speaker	GPA-600				
YAMAHA	TYROS	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	GKC-1648
YAMAHA	TYROS2	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	
YAMAHA	YPG225	Keyboard	GKB-76	GK-76	GK-276R	G-Tour 76	GKC-1648
YAMAHA	YPG525	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	GKC-1648
YAMAHA	YPG625	Keyboard	GKB-88	GK-88	GK-288R	G-Tour 88	GKC-1648
YORKVILLE	AP818	Mixer	G-MIX 20 x 25	G-MIX 20 x 30	G-TOUR 20 x 25	G-TOUR 20 x 30	GMC-3333
YORKVILLE	MAX16	Mixer	G-MIX 20 x 30	G-MIX 24 x 36	G-TOUR 20 x 30	G-TOUR 24 x 36	GMC-3333
YORKVILLE	MAX22	Mixer	G-MIX 24 x 36	G-TOUR 24 x 36	GMC-4221		
ZENITH	P42W22B	LCD/Plasma	G-TourLCDP3743				
ZENITH	P42W24B/P	LCD/Plasma	G-TourLCDP3743				
ZENITH	P42W34/34H	LCD/Plasma	G-TourLCDP3743				
ZENITH	P42W46X	LCD/Plasma	G-TourLCDP3743				
ZENITH	P50W28B	LCD/Plasma	G-TourLCDP50				
ZENITH	P50W38/38H	LCD/Plasma	G-TourLCDP50				
ZOOM	MRS1044	Recording Workstation	G-TOUR 12X17	GMC-2222			
ZOOM	MRS1608CD	Recording Workstation	G-MIX-B 2020	G-MIX-L 1822	G-MIX 19X21	G-TOUR 19X21	GMC-2222
ZOOM	MRS802BCD	Recording Workstation	G-TOUR 12X17	GMC-2222			

This list is intended as a guide; not a substitute for testing the actual fit of an instrument. All product information referenced above is based on the manufacturer's published specifications. These specifications may change over time and without notice. If you have questions on a specific case or product, or see that a correction is needed, please contact Gator Customer Service at 813.221.4191 or send us an email at info@gatorcases.com.

Gator Cases Master Cross Reference

Interior Case Dimensions (inches)

Standard

Keyboard Cases

Model	Length	Width	Height
GK-2110	22.5	11	4
GK-261R	44	17.25	6
GK-276R	51.25	18	6
GK-288R	59	19	6.5
GK-288R SL	54	15	6
GK-49	38	15	5.5
GK-61	43	17.5	6.5
GK-76	51.5	18	6.5
GK-88	57.5	18	6
GK-88 SL	54	15	6
G-TOUR-61	44	17.38	6
G-TOUR-76	51.25	18	6
G-TOUR-88	59	19	6.63
G-TOUR-88 SL	54	15	6

Mixer Cases

Model	Length	Width	Height
G-MIX 12 x 24	23.25	12	4.25
G-MIX 17 x 18	18	17	7
G-MIX 19 x 21	21	19	7.5
G-MIX 20 X 25	25	20	8
G-MIX 20 x 30	30	20	6.25
G-MIX 22 x 46	46	22	6.5
G-MIX 24 x 36	36	24	6.5
G-MIX-B 1212	12	12	4
G-MIX-B 1515	15	15	5.5
G-MIX-B 1818	18	18	5.5
G-MIX-B 2020	20	20	5.5
G-MIX-L 1224	24	11.75	5
G-MIX-L 1618	18	16	6
G-MIX-L 1622	22	16	5.5
G-MIX-L 1822	22	18	7.5
G-TOUR 12 x 17	17	12	7.5
G-TOUR 19 x 21	21	19	7
G-TOUR 20 x 25	25	20	8
G-TOUR 20 x 30	30	20	6.25
G-TOUR 24 x 36	36	24	6.5
GPA-720	21	13.5	13.5

Laptop/Gear Cases

Model	Length	Width	Height
GAV-1412R (gear compartment) <i>Fits Laptops up to 14" x 12"</i>	14	12	4
GAV-1813R (gear compartment) <i>Fits Laptops up to 18" x 13"</i>	18	13	4
GAV-20 (gear compartment) <i>Fits Laptops up to 14" x 10.5"</i>	15	11	6
GAV-DLX-1412R (gear compartment) <i>Fits Laptops up to 14" x 12"</i>	14	12	4
GAV-DLX-20 (gear compartment) <i>Fits Laptops up to 14" x 10.5"</i>	15	11	6
GAV-PE-1412R (gear compartment) <i>Fits Laptops up to 14" x 12"</i>	14	12	4

Amp Cases

Model	Length	Width	Height
G-112	25	19.5	12
G-212	30	23.25	12
G-901	30	12.5	10.5
GPA-720	20	13.5	13
G-TOUR 4x12 CAB	32	32	17
G-TOUR-AMP 2226	26	22	13
G-TOUR-AMP 2430	30	24	13
G-TOUR AMP HEAD	32	14	12

Gator Cases Master Cross Reference
 Interior Case Dimensions (inches)

Metric

Keyboard Cases

Model	Length	Width	Height
GK-2110	562.5	275	100
GK-261R	1100	431.25	150
GK-276R	1281.25	450	150
GK-288R	1475	475	162.5
GK-288R SL	1350	375	150
GK-49	950	375	137.5
GK-61	1075	437.5	162.5
GK-76	1287.5	450	162.5
GK-88	1437.5	450	150
GK-88 SL	1350	375	150
G-TOUR-61	1100	434.5	150
G-TOUR-76	1281.25	450	150
G-TOUR-88	1475	475	165.75
G-TOUR-88 SL	1350	375	150

Mixer Cases

Model	Length	Width	Height
G-MIX 12 x 24	581.25	300	106.25
G-MIX 17 x 18	450	425	175
G-MIX 19 x 21	525	475	187.5
G-MIX 20 X 25	625	500	200
G-MIX 20 x 30	750	500	156.25
G-MIX 22 x 46	1150	550	162.5
G-MIX 24 x 36	900	600	162.5
G-MIX-B 1212	300	300	100
G-MIX-B 1515	375	375	137.5
G-MIX-B 1818	450	450	137.5
G-MIX-B 2020	500	500	137.5
G-MIX-L 1224	600	293.75	125
G-MIX-L 1618	450	400	150
G-MIX-L 1622	550	400	137.5
G-MIX-L 1822	550	450	187.5
G-TOUR 12 x 17	425	300	187.5
G-TOUR 19 x 21	525	475	175
G-TOUR 20 x 25	625	500	200
G-TOUR 20 x 30	750	500	156.25
G-TOUR 24 x 36	900	600	162.5
GPA-720	525	337.5	337.5

Laptop/Gear Cases

Model	Length	Width	Height
GAV-1412R (gear compartment) Fits Laptops up to 350 x 300	350	300	100
GAV-1813R (gear compartment) Fits Laptops up to 450 x 325	450	325	100
GAV-20 (gear compartment) Fits Laptops up to 350 x 262.5	375	275	150
GAV-DLX-1412R (gear compartment) Fits Laptops up to 350 x 300	350	300	100
GAV-DLX-20 (gear compartment) Fits Laptops up to 350 x 262.5	375	275	150
GAV-PE-1412R (gear compartment) Fits Laptops up to 350 x 300	350	300	100

Amp Cases

Model	Length	Width	Height
G-112	625	487.5	300
G-212	750	581.25	300
G-901	750	312.5	262.5
GPA-720	500	337.5	325
G-TOUR 4x12 CAB	800	800	425
G-TOUR-AMP 2226	650	550	325
G-TOUR-AMP 2430	750	600	325
G-TOUR AMP HEAD	800	350	300